

RV 4116 - RV 4118

Operation and maintenance manual

Edition	11/2010
Printing date	xxx
Language	GB
Series	xxx
Serial number	xxx
Code	9820D11GB



RV 4116 - RV 4118

ROUND BALERS

Keep this manual in a well-known and easily accessible place, in order to have it always at disposal when you need to read it.

The user and maintenance information, which is an integral part of agricultural machinery, **MUST ALWAYS BE KEPT IN THE DRIVER'S SEAT** of the tractor to which the machine is combined.

IMPORTANT: *The text of the document is the translated version of the Italian manual (original language), identified by code number 9820D11IT.*

Cod. 9820D11GB	Ed. 11/2010
I ► n.XXXXXX	► I
Per approvazione.....	

1	Kverneland Group Kerteminde AS Taarupstrandvej 25, DK-5300 KERTEMINDE, Denmark		
2	RF3120 - RF3150 - RF3225 - RF3250 - RF3255 - RF3325 RV4116 - RV4118 - RV4216 - RV4220 SB1100 - SB1200 - SB1300		
3	160000- 163000	4	Mr. Claus Udengaard Thomsen

Mr. Claus Udengaard Thomsen-CEO of Kverneland Group Kerteminde AS

Kerteminde, 01/10/2010

IT DICHIARAZIONE CE DI CONFORMITÀ
L'Azienda (1) dichiara sotto la propria responsabilità che la macchina agricola con funzione di **PRESSA RACCOLTRICE** realizzata nei modelli elencati (2) ognuno dei quali identificabile da un numero di serie compreso fra i valori (3) è conforme alle **Direttive Europee: 2006/42/CE** e successive modifiche - **2004/108/CE** e successive modifiche - **2002/96/CE** e successive modifiche - **97/23/CE** e successive modifiche
Norme Armonizzate applicate: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998
Specifiche Tecniche applicate: ISO 11684:1995
Responsabile (4), autorizzato a costituire il **Fascicolo Tecnico**

EN EC DECLARATION OF CONFORMITY
The Company (1) declares, under its sole responsibility, that the agricultural machinery with the function of, **PICK-UP BALER** manufactured in the listed models (2) each of them is identified by a serial number included between values (3) complies with the following **European Directives: 2006/42/EC** and subsequent amendments - **2004/108/EC** and subsequent amendments - **2002/96/EC** and subsequent amendments - **97/23/EC** and subsequent amendments
Applied harmonised standards: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998
Applied technical specifications: ISO 11684:1995
Responsible (4), authorised to manufacture the **Technical File**

FR DECLARATION DE CONFORMITE CE
L'Entreprise (1) déclare sous sa seule responsabilité que la machine agricole faisant fonction de **RAMASSEUSE-PRESSE** réalisée selon les modèles spécifiés (2) chacun desquels se caractérise par un numéro de série compris entre les valeurs (3) est conforme aux **Directives Européennes** suivantes: **2006/42/CE** et ses modifications successives - **2004/108/CE** et ses modifications successives - **2002/96/CE** et ses modifications successives - **97/23/CE** et ses modifications successives
Normes Harmonisées appliquées: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998
Consignes Techniques appliquées: ISO 11684:1995
Responsable (4) autorisé à rédiger le **Dossier Technique**

DE EU-KONFORMITÄTSERKLÄRUNG
Die Firma (1) erklärt unter eigener Verantwortung, dass die landwirtschaftliche Maschine mit den folgenden Funktionen **AUFSAMMELPRESSE** in den aufgeführten Modellen (2), die jeweils durch eine Seriennummer zwischen den Werten (3) gekennzeichnet sind, entspricht den folgenden **Europäischen Richtlinien: 2006/42/EG** und den darauffolgenden Abänderungen - **2004/108/EG** und den darauffolgenden Abänderungen - **2002/96/EG** und den darauffolgenden Abänderungen - **97/23/EG** und den darauffolgenden Abänderungen
Gültige Harmonisierte Normen: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998
Gültige Technische Spezifikationen: ISO 11684:1995
Bevollmächtigter für die Erstellung der **technischen Unterlagen**

DA EF-OVERENSSTEMMELSESERKLÆRING
Firmaet (1) erklærer under eget ansvarat landbrugsmaskinen med funktionen **BALLEPRESSER** produceret i følgende modeller (2) og som hver især identificeres af et serienummer indenfor værdierne (3) opfylder følgende **Europæiske Direktiver: 2006/42/EF** og senere ændringer - **2004/108/EF** og senere ændringer - **2002/96/EF** og senere ændringer - **97/23/EF** og senere ændringer
Anvendte Harmoniserede Standarder: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998
Anvendte Tekniske Specifikationer: ISO 11684:1995
Ansvarlig (4), bemyndiget til udarbejdelsen af det **tekniske dossier**

ES DECLARACIÓN DE CONFORMIDAD CE
La empresa (1) declara bajo su responsabilidad que la máquina agrícola con función de **PRESA RECOGEDORA** realizada en los modelos indicados (2), cada uno de los modelos se puede identificar mediante un número de serie incluido entre los valores (3) cumple las siguientes **Directivas Europeas: 2006/42/CE** y sucesivas modificaciones - **2004/108/CE** y sucesivas modificaciones - **2002/96/CE** y sucesivas modificaciones - **97/23/CE** y sucesivas modificaciones
Normas armonizadas aplicadas: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998
Especificaciones técnicas aplicadas: ISO 11684:1995
Responsable (4), autorizado para realizar el **Expediente Técnico**

ET EÜ VASTAVUSDEKLARATSIOON
Ettevõtte (1) deklareerib omal vastutusel, et põllumajandusmasin mille funktsioon on **PRESSKOGUR** mida valmistatakse loendatud mudelitelena, millest igaüks on identifitseeritav seeriainumbri vahel mis jääb vaartuste (3) vahele, vastab järgmistele **Euroopa direktiividele: 2006/42/EÜ** (muudetud kujul) - **2004/108/EÜ** (muudetud kujul) - **2002/96/EÜ** (muudetud kujul) - **97/23/EÜ** (muudetud kujul)
Kohaldatavad ühtlustatud standardid: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998
Kohaldatavad tehnilised kirjeldused: ISO 11684:1995
Vastutav isik (4), kellel on volitused tähtsate **tehnilise dokumentatsiooni** koostamiseks

FI EY:N DIREKTIIVIEN
Yritys (1) vakuuttaa omalla vastuullaan, että maatalouskone, jonka käyttötarkoitus on **KOKOOJAPPAALAIN** josta on valmistettu luettelossa mainittu mallit (2), joista jokainen on tunnistettavissa sarjanumerosta, joka on arvoltaan välillä (3), noudattaa seuraavien **europaalaisten direktiivien** vaatimuksia: **2006/42/EY** ja myöhemmät muutokset - **2004/108/EY** ja myöhemmät muutokset - **2002/96/EY** ja myöhemmät muutokset - **97/23/EY** ja myöhemmät muutokset
Sovelletut harmonisoidut standardit: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998
Sovelletut tekniset eritelmät: ISO 11684:1995
Teknisen asiakirja-aineiston laatimiseen valtuutettu henkilö (4)

NL EG-CONFORMITEITSVERKLARING
Het Bedrijf (1) verklaart geheel onder eigen verantwoordelijkheid dat de landbouwmachine met de functie van **VERGAARPERS** vervaardigd in de vermelde modellen (2) waarvan elk model geïdentificeerd kan worden aan de hand van een serienummer tussen de waarden (3) in overeenstemming is met de volgende **Europese Richtlijnen: 2006/42/EG** en latere wijzigingen daarop - **2004/108/EG** en latere wijzigingen daarop - **2002/96/EG** en latere wijzigingen daarop - **97/23/EG** en latere wijzigingen daarop
Toegepaste Geharmoniseerde Normen: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998
Toegepaste Technische Specificaties: ISO 11684:1995
Verantwoordelijke (4) die bevoegd is het **Technische Dossier** samen te stellen

PT DECLARAÇÃO CE DE CONFORMIDADE
A empresa (1) declara sob a sua responsabilidade que a máquina agrícola com função de **ENFARDADEIRA** realizada nos modelos enumerados (2), cada um dos quais identificável por um número de série, compreendido entre os valores (3), está conforme com as seguintes **Directivas Europeias: 2006/42/CE** e sucessivas alterações - **2004/108/CE** e sucessivas alterações - **2002/96/CE** e sucessivas alterações - **97/23/CE** e sucessivas alterações
Normas Harmonizadas aplicadas: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998
Especificações Técnicas aplicadas: ISO 11684:1995
Responsável (4), autorizado a preencher o **Processo Técnico**.

BG ДЕКЛАРАЦИЯ НА ЕО ЗА СЪОТВЕТСТВИЕ
Фирмата (1) декларира на собствена отговорност, че селскостопанската машина работеща като **СЪБИРАТЕЛНА ПРЕСА** произведена в изброените модификации (2) всяка от които се различава по сериен номер в рамките на стойностите (3) отговаря на следните **Европейски Директиви: 2006/42/CE** и последващите промени - **2004/108/CE** и последващите промени - **2002/96/CE** и последващите промени - **97/23/CE** и последващите промени
Приложени Хармонизирани Нормативи: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998
Приложени Специфични Техники: ISO 11684:1995
Отговорно лице (4), упълномощено да състави **техническото досие**.

CS PROHLÁŠENÍ O SHODĚ PODLE EC
Firma (1) na vlastní zodpovědnost prohlašuje, že zemědělský stroj s funkcí **SBĚRNÝ LIS** vyrobený v uvedených modelech (2), z nichž každý je označen sériovým číslem o hodnotě mezi (3), je v souladu s následujícími **evropskými směrnici: 2006/42/ES** v platném znění - **2004/108/ES** v platném znění - **2002/96/ES** v platném znění - **97/23/ES** v platném znění
Aplikované harmonizované předpisy: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998
Aplikované technické specifikace: ISO 11684:1995
Zodpovědná osoba (4) zmocněná vypracováním **technické složky**

1	Kverneland Group Kerteminde AS Taarupstrandvej 25, DK-5300 KERTEMINDE, Denmark		
2	RF3120 - RF3150 - RF3225 - RF3250 - RF3255 - RF3325 RV4116 - RV4118 - RV4216 - RV4220 SB1100 - SB1200 - SB1300		
3	160000- 163000	4	Mr. Claus Udengaard Thomsen

SL	IZJAVA ES O SKLADNOSTI
<p>Podjetje (1) izjavlja pod lastno odgovornostjo, da je kmetijski stroj s funkcijo ZBIRALNE PREŠE v navedenih modelih (2), ki jih je mogoče identificirati na podlagi serijske številke med vrednostmi (3) v skladu s sledečimi evropskimi direktivami: 2006/42/CE in s kasnejšimi spremembami - 2004/108/CE in s kasnejšimi spremembami - 2002/96/CE in s kasnejšimi spremembami - 97/23/CE in s kasnejšimi spremembami</p> <p>Upoštewane harmonizirane norme: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998</p> <p>Upoštewane tehnične značilnosti: ISO 11684:1995</p> <p>Odgovorna oseba (4), pooblaščenca za sestavo Tehničnega zvezka</p>	

NO	EF-SAMSVARERKLÆRING
<p>Selskapet (1) bekrefter under dets ansvar at landbruksmaskinene med funksjonene RUNDBALLPRESSE realisert med modellene som er oppført (2) som hver kan identifiseres av et serienummer blandt verdiene (3) i samsvar med følgende EU-direktiv: 2006/42/EF og senere endringer - 2004/108/EF og senere endringer - 2002/96/EF og senere endringer - 97/23/EF og senere endringer</p> <p>Harmoniserte standarder som er brukt: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998</p> <p>Tekniske spesifikasjoner som er brukt: ISO 11684:1995</p> <p>Ansvarlig (4), som er autorisert til å endre og opprette de tekniske dokumenter.</p>	

HU	EK MEGFELELŐSÉGI NYILATKOZAT
<p>A Cég (1) saját felelőssége tudatában kijelenti, hogy a mezőgazdasági gép, a PRÉSELŐ, ARATÓ a (2) felsorolt típusokban készített amelyeknek mindegyike a (3) értékei közötti sorozatszámmal azonosítható konformis a következő Európai Irányelvekkel: 2006/42/EK és következő módosításai - 2004/108/EK és következő módosításai - 2002/96/EK és következő módosításai - 97/23/EK és következő módosításai</p> <p>Alkalmazott Harmonizáló Szabványok: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998</p> <p>Alkalmazott Speciális Módszerek: ISO 11684:1995</p> <p>A Műszaki Dokumentáció összeállításáért Meghatalmazott (4)</p>	

LT	EB ATITIKTIES DEKLARACIJA
<p>Įmonė (1) prisiimdama atsakomybę pareiškia, kad žemės ūkio mašina, kurioje yra šios funkcijos RINKIMO PRESAS pagaminta išvardytais modeliais (2), kurių kiekvienas identifikuojamas serijos numeriu, atitinkančiu šias vertes (3), atitinka šias ES direktyvas: 2006/42/CE ir jų pakeitimus - 2004/108/CE ir jų pakeitimus - 2002/96/CE ir jų pakeitimus - 97/23/CE ir jų pakeitimus</p> <p>Taikomos harmonizuotos normos: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998</p> <p>Taikomos techninės specifikacijos: ISO 11684:1995</p> <p>Techinė byla sudaryta paliotas atsakingas asmuo (4)</p>	

LV	EK ATBILSTĪBAS DEKLARĀCIJA
<p>Uzņēmums (1) deklarē zem savas atbildības, ka lauksaimniecības mašīna ar funkciju SAVĀCĒJPRESĒ kas ir izveidota uzrādītajos modeļos (2), katrs no kuriem ir atpazīsātams ar sērijas numuru starp vērtībām (3) atbilst sekojošām Eiropas Direktīvām: 2006/42/EK un tālākām izmaiņām - 2004/108/EK un tālākām izmaiņām - 2002/96/EK un tālākām izmaiņām - 97/23/EK un tālākām izmaiņām</p> <p>Piemērotā Harmonizētā Norma: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998</p> <p>Piemērotā Tehniskā Ipatnība: ISO 11684:1995</p> <p>Atbildīgā persona (4), kurai ir atļauts sastādīt Tehnisko Mapi.</p>	

SV	FÖRETAGETS FÖRKLARING OM ÖVERENSSTÄMMELSE
<p>Företaget (1) förklarar under eget ansvar att jordbruksmaskinen med funktion som PRE som har tillverkats i de nämnda modellerna (2) som var och en kan identifieras av ett serienummer som innefattas mellan värdena (3) överensstämmer med följande Europeiska Direktiv: 2006/42/CE och senare tillägg - 2004/108/CE och senare tillägg - 2002/96/CE och senare tillägg - 97/23/CE och senare tillägg</p> <p>ämpbara Harmoniserade Standarder: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998</p> <p>ämpbar Teknisk Specifikation: ISO 11684:1995</p> <p>Ansvarig (4), auktoriserad att sammanställa den Tekniska Specifikationen</p>	

EL	ΔΗΛΩΣΗ ΣΥΜΜΟΡΦΩΣΗΣ EC
<p>Η Επιχείρηση (1) δηλώνει με δική της ευθύνη ότι η γεωργική μηχανή με λειτουργία ΧΟΡΤΟ-ΣΥΛΛΕΚΤΟ-ΔΕΤΙΚΗ ΜΗΧΑΝΗ πραγματοποιημένη στα παρακάτω μόντελα (2) καθένα από τα οποία τροπορίζεται με επιπλέον σειράς μεταξυ των τιμών (3) συμφωνεί στις παρακάτω Ευρωπαϊκές Οδηγίες: 2006/42/ΕΚ και επόμενες τροποποιήσεις - 2004/108/ΕΚ και επόμενες τροποποιήσεις - 2002/96/ΕΚ και επόμενες τροποποιήσεις - 97/23/ΕΚ και επόμενες τροποποιήσεις</p> <p>Εφαρμοσμένα Εναρμονισμένα Πρότυπα: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998</p> <p>Εφαρμοσμένες Τεχνικές προδιαγραφές: ISO 11684:1995</p> <p>Υπεύθυνος (4), εξουσιοδοτημένος να πραγματοποιήσει το Τεχνικό Φυλλάδιο</p>	

PL	DEKLARACJA ZGODNOŚCI WE
<p>Firma (1) deklaruje na własną odpowiedzialność, że maszyna rolnicza działająca jako PRASA ROLNICZA wykonana w wymienionych modelach (2), z których każdy można zidentyfikować dzięki numerowi seryjnemu zawarem między wartościami (3) spełnia wymogi następujących Dyrektyw Europejskich: 2006/42/WE i ich kolejnych poprawek - 2004/108/WE i ich kolejnych poprawek - 2002/96/WE i ich kolejnych poprawek - 97/23/WE i ich kolejnych poprawek</p> <p>Zastosowane Normy Zharmonizowane: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998</p> <p>Zastosowane Rozwiązania Techniczne: ISO 11684:1995</p> <p>Oseba (4), upoważniona do sporządzania Dokumentacji Technicznej</p>	

RO	DECLARAȚIE DE CONFORMITATE CE
<p>Firma (1) declară pe propria răspundere că mașina agricolă cu funcția de PRESĂ DE RECOLTAT realizată în modelele enumerate (2) fiecare identificabil printr-un număr de serie cuprins între valorile (3) este conform următoarelor Directive Europene: 2006/42/CE și modificărilor succesive - 2004/108/CE și modificărilor succesive - 2002/96/CE și modificărilor succesive - 97/23/CE și modificărilor succesive</p> <p>Standarde Armonizate aplicate: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998</p> <p>Specificații Tehnice aplicate: ISO 11684:1995</p> <p>Responsabil (4), autorizat să constituie Dosarul Tehnic</p>	

SK	PREHLÁSENIE OZHODES ES
<p>Firma (1) na vlastnú zodpovednosť prehlasuje, že poľnohospodársky stroj s funkciou ZBERNÝ LIS vyrobený v uvedených modeloch (2), z ktorých každý je označený sériovým číslom s hodnotou medzi (3), je v súlade s nasledujúcimi európskymi smernicami: 2006/42/ES v platnom znení - 2004/108/ES v platnom znení - 2002/96/ES v platnom znení - 97/23/ES v platnom znení</p> <p>Aplikované harmonizované predpisy: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998</p> <p>Aplikované technické špecifikácie: ISO 11684:1995</p> <p>Zodpovedná osoba (4) zmocnená vypracovaním technickej zložky</p>	

TR	ATUYGUNLUK BEYANI
<p>Üretici Firma (1) kendi sorumluluğunu altından aşağıdaki işlevlere sahip BALYA MAKİNESİ her biri (3) değeri arasında bir seri numarası ile tanımlanabilen ve listelenen modellerde (2) üretilen tarım makinesinin - 2006/42/CE, 2004/108/CE, 2002/96/CE, 97/23/CE Avrupa Direktiflerine ve takip eden değişikliklerine uygun olduğunu beyan eder.</p> <p>Uygulanan Uyumlaştırılmış Standartlar: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998</p> <p>Uygulanan Teknik Şartnameler: ISO 11684:1995</p> <p>Teknik Fasikül'ü hazırlama yetkisine sahip yetkili (4)</p>	

MT	DIKJARAZZJONI TA' KONFORMITÀ TAL-KE
<p>Il-Kupanija (1) tiddikjara fuq ir-responsabbiltà unika tagħha li l-makkinarju agrikuoli li jintuza bħala BALER indikat fil-mudelli elenkati (2) kull wiehed minnhom identifikabbli b'numru tas-serje bejn il-valuri (3) huwa konformi mad-Direttiva Ewropea: 2006/42/KE u emendi sussegwenti - 2004/108/KE u emendi sussegwenti - 2002/96/KE u emendi sussegwenti - 97/23/KE u emendi sussegwenti</p> <p>Normi Armonizzati applikati: UNI EN 704:2001 / EN ISO 4254-1:2009 / UNI EN ISO 3767-2:1998</p> <p>L-ispeċifikazzjonijiet Tekniċi applikati: ISO 11684:1995</p> <p>Responsabbli (4), awtorizzat li jikkostitwixxi l-Fajl Tekniku</p>	

GENERAL AND SAFETY INFORMATION

Purpose of this manual	3
User's manual	4
Manufacturer and machine identification	4
Procedure to request technical assistance	5
Glossary and terminology	5
Attached documentation	5
General safety rules	6
Safety rules about loading and transport operations	6
Safety rules about use and operation	7
Safety rules about road circulation	9
Safety rules about maintenance and adjustments	10
Safety rules for the environmental impact	11
Description of safety signs	11

GENERAL INFORMATION ABOUT THE MACHINE

General description of the machine	15
Operation cycle	18
Improper use	20
Residual risks	20
Areas of danger	21
Night work	21
Technical data RV 4116 f	22
Technical data RV 4116 R	24
Technical data RV 4118 F	26
Technical data RV 4118 r	28
Allowable slopes	30
Equipment	30
Fittings on demand	32
Safety devices	33
Oil-pressure devices	35
Electronic and electric devices	36
Position of information and safety plates	37
Instructions for handling and loading	39
Packing and unpacking	39
Loading and unloading	39
Machine-tractor combination	41
How to set the height of the drawbar	42
How to set the length of the cardan shaft	43
Instructions for use and operation	46
How to couple the machine to the tractor	47
How to uncouple the machine from the tractor	49
How to open the guards	51
Instructions and suggestions for use	51
How to set bale diameter	54
How to set bale density	54
Road circulation	56
How to adjust transmission chains	57
How to adjust centralised lubrication	57
How to adjust belt alignment	58
How to adjust the cleaning rollers	60
Instructions for maintenance	61
Programmed maintenance intervals chart	61
Lubricant table	64
Driving torque table	65
Lubrication points diagram	65
Check of belt alignment	67
Change of reduction gear oil	67

Oil supply for centralised lubrication	68
How to clean the belt guiding rollers	68
How to store the machine at season end	70
Putting the machine into service	71
Special maintenance	71
Instructions for part replacement	71
How to replace the tyres	72
How to replace the belts of the baling chamber	73
Manual equipment for vice ("MATO" type junctions)	74
Machine disposal	80
Machine demolition	80

FAILURE INFORMATION

Troubles, causes, remedies	81
----------------------------------	----

PICK-UP UNIT (WIDE TYPE)

General description	87
Oil-pressure devices	88
How to handle the pick-up unit	88
How to remove product clogging in the pick-up unit	89
How to balance the pick-up unit	89
How to adjust the height of the pick-up unit	90
How to adjust the fixed baffle plate	90
How to adjust the tilting baffle plate	91
How to adjust the pick-up transmission chain	92
How to replace the safety bolt	93

PICK-UP UNIT (EXTRA-LARGE TYPE)

General description	95
Oil-pressure devices	96
How to handle the pick-up unit	96
How to remove product clogging in the pick-up unit	97
How to balance the pick-up unit	97
How to adjust the height of the pick-up unit	98
How to adjust the tilting baffle plate	98
How to adjust the pick-up transmission chain	99

FEEDING UNIT (ROTOR)

General description	101
Electrical devices	102
Oil-pressure devices	102
How to unflood the feeding unit	103

PRODUCT FEEDING UNIT (WITH SIMPLE FEEDER)

General description	105
Product clogging removal in the feeding unit	106
How to replace the safety bolt	107

NET BINDER UNIT (ELECTRONIC)

General description	109
Electrical devices	110
Net reel supply	110
How to adjust the braking device	112
How to adjust the pressure of the net driving rollers	112
How to adjust the cut reset device	113
How to deactivate and activate the cutting device	113
How to clean the net driving rollers	114
How to replace the electro-clutch belt	115

TWINE BINDER UNIT (ELECTRONIC)

General description..... 117
 Electrical devices 118
 How to introduce the twine 118
 How to supply the twine reels 120
 How to adjust the twine tightening clamps..... 123
 How to adjust the chains of the twine guiding arms... 123
 How to replace the blade 124

ATTACHMENTS

Electrical components diagram..... 126
 Electrical components spare parts diagram..... 128
 "Control unit" drilling diagram (ECU) 129
 "Control unit" wiring diagram and
 decalcomania (ECU)..... 130
 CAN cable..... 131
 Supply cable 132
 Electro-clutch cable 133
 Bale density/diameter cable..... 134
 Direction indicator cable 135
 Sensor cable 0° 136
 Sensor cable 90° 137
 Solenoid valve cable..... 138
 Picture..... 139
 Hydraulic system diagram for machines with simple
 feeder and fixed pick-up 144
 Hydraulic system diagram of the machines with rotating
 feeder (with "Drop Floor") and fastened pick-up..... 146
 Rotor hydraulic unit with "Drop floor" 148
 Gate/bale density hydraulic system diagram 150
 Tail gate/bale density hydraulic control valve 152

PURPOSE OF THIS MANUAL

- This manual, which is an integral part of the machine, was made by the manufacturer to supply the information that is necessary for the operator (driver of the tractor to which the machine has been coupled), who is authorised to interact with the machine during all uses (operation, maintenance, etc.).
- All pieces of information are supplied in the Manufacturer's mother tongue (Italian) and they can be translated into other languages to meet trading and/or legislative needs.
- The translations in the language of the country of utilisation, provided by the manufacturer, have been carried out directly from the "ORIGINAL INSTRUCTIONS".
If the translations are realised by the mandatory agent or whoever issues the machine in the linguistic zone in consideration, they must carry out the translation starting from the original instructions and the following writing must be shown: "TRANSLATION FROM THE ORIGINAL INSTRUCTIONS".
- The information aims at awakening the users to be extremely careful to prevent possible risks. Caution is always irreplaceable. Safety is also put in the hands of the personnel who work with the machine during its operating period.

Carefully read the instructions that are specified in the supplied manual and the ones that have been directly stuck on the machine; make sure that you understand them well, especially safety instructions.

- Dedicate a bit of time to read the instructions to prevent unpleasant accidents. When an accident occurs, it is too late to remember that you had to behave differently.

Keep this manual in a well-known and easily accessible place, in order to have it always at disposal when you need to read it.

Keep this manual in a well-known and easily accessible place, in order to have it always at disposal when you need to read it.

The user and maintenance information, which is an integral part of agricultural machinery, MUST ALWAYS BE KEPT IN THE DRIVER'S SEAT of the tractor to which the machine is combined.

To easily find out the specific topics of interest, read the table of contents and the index.

- The manual is structured into parts, which are collected according to the layout of the reference machine.
Some pieces of information that are mentioned in the manual may not completely match the real layout of the delivered machine. This does not influence the relevant understanding and does not compromise their safety level.
- The manufacturer reserves the right to modify the manual without the duty to previously communicate it, provided that it does not compromise the health and the safety of operators.
- To highlight certain essential parts of the text and to indicate important specifications, several symbols have been adopted.



Danger Warning

Indicates extremely dangerous situations that, if disregarded, may seriously endanger the health and safety of persons.



Caution Precaution

Indicates that suitable practices must be adopted to avoid the risk of injuries and damages.



Important

Indicates particularly important technical information that should not be disregarded

USER'S MANUAL

The manual is structured into parts, which are collected according to the layout of the reference machine.

The list shows a brief description of the units that, coupled together, form the layout of the machine.


- **General and safety information (part 1):** it includes the information to consult the manual and the safety details.
- **General machine information (part 2):** it includes the information about the functionalities, the main features and the different intervention modes (handling, coupling to the tractor, adjustment, maintenance, etc.) of the machine.
- **Information about failures (part 3):** it includes the information about the irregularities of all working units (tabular structure), which can occur during the normal operation.
- **Pick-up unit (part 4):** it includes the information about the functionalities, the main features and the different intervention modes (adjustment, maintenance, etc.) for the type of unit that has been installed in the machine.
- **Feeding unit (part 5):** it includes the information about the functionalities, the main features and the different intervention modes (adjustment, maintenance, etc.) for the type of unit that has been installed in the machine.
- **Net binder unit (part 6):** it includes the information about the functionalities, the main features and the different intervention modes (adjustment, maintenance, etc.) for the type of unit that has been installed in the machine.
- **Twine binder unit (part 7):** it includes the information about the functionalities, the main features and the different intervention modes (adjustment, maintenance, etc.) for the type of unit that has been installed in the machine.
- **Attachments (part 8):** it includes the information (structured as diagrams) about three functionalities and the features of the systems (electric, hydraulic, etc.).
- **Specialised interventions (booklet 9):** contain the information on the various intervention procedures (setting, maintenance, etc.) of the types of units installed on the machine, reserved exclusively for specialised technicians.
- **Electronic control system:** it is delivered together with the user and maintenance manual, and includes the information about the functionalities, the features and the programming modes.

MANUFACTURER AND MACHINE IDENTIFICATION

The displayed identification plate is directly stuck on the machine. It lists traceability details and references to be used when asking for technical support and/or ordering spare parts.

The plate also specifies the minimum instructions that are necessary for the coupling to the tractor.

- A) Manufacturer ID
- B) Machine mark
- C) Machine model
- D) Serial number
- E) Year of fabrication



- F) Total weight (kg)
- G) Mass on lifting eye (kg)
- H) Mass on axle (kg)
- L) Approval data

PROCEDURE TO REQUEST TECHNICAL ASSISTANCE.

In case of need, call the After-Sales Service of the manufacturer, of the local dealer or an authorised workshop.

If you ask for technical support concerning the machine, specify the data listed in the identification plate, the approximate work hours and the type of problem being detected.

GLOSSARY AND TERMINOLOGY

A few terms which are widely used in the manual are described below to better explain their meaning.

- Routine maintenance:** set of operations that are necessary to keep the functionality, the efficiency and the safety requirements of the machine. The manufacturer establishes the intervals between the interventions and, if necessary, also establishes the performance modes for those operations that imply particular procedures.
- Operator:** person that has been selected and authorised among the personnel who have the qualifications, the competences and the knowledge that are necessary to drive the tractor to which the machine is coupled, and who are also capable of performing the production activity autonomously, as well as in an adequate, correct and riskless way.

ATTACHED DOCUMENTATION

The specified documentation is supplied together with the manual and/or as an attachment.

- Declaration of conformity
- Test certificate
- Declaration of conformity to the type of machine that is approved for road use (only in Italy)
The declaration of conformity to the approved type must be used to ask for the vehicle registration document to the Driver and Vehicle Licensing Centre.
- Documentation about the installed commercial components (for example, the documentation about the cardan shaft)
- Wiring diagrams
- Hydraulic diagrams
- User manual of the electronic control system.

GENERAL SAFETY RULES


- When designing and manufacturing the machine, the Manufacturer paid special attention to the aspects that may endanger the safety and health of the people working with the machine.
Besides the compliance with the laws in force, the Manufacturer applies all "code of practice rules".
- Carefully read the instructions that are specified in the supplied manual and the ones that have been directly stuck on the machine; make sure that you understand them well, especially safety instructions.
- Dedicate a bit of time to read the instructions to prevent unpleasant accidents. When an accident occurs, it is too late to remember that you had to behave differently.
- Pay attention to the information signs that are directly stuck to the machine.
Information signs can have different colours and shapes to warn about dangers, obligations, prohibitions and instructions.
- Information signs must be kept readable and the instructions specified in them must be complied with.
- Do not tamper with, escape, remove or bypass the safety devices that are installed in the machine. If this requirement is not met, people's safety and health may be seriously compromised.
- The personnel that, during the entire operating life of the machine, perform any type of intervention in the same machine must have recognised competences and skills in the specific sector. If the aforesaid requirements are missing, damages to the health and safety of people may occur.

SAFETY RULES ABOUT LOADING AND TRANSPORT OPERATIONS

- The personnel in charge of loading, unloading and handling the machine must be competent and skilled according to the specific sector and must be in command of the means to be used.
- If, during the life of the machine, it is necessary to load and unload it on a means of transport, the personnel in charge must comply with the pieces of information that are directly specified on the machine, on its package and in the user manual.
- Lift and transport the machine by using suitable means having an adequate capacity.
- Before loading the machine by using a tractor, disconnect the cardan shaft from the tractor and the feeding systems (electric power, hydraulic system, etc.).
- Before disconnecting the machine from the tractor, position the support in a suitable way to make the following connection easier.
- Before transferring the machine onto a means of transport, make sure that the machine and its components are suitably fastened, and that their loading gauge does not exceed the maximum overall dimensions being provided for. If necessary, prearrange suitable signs.


SAFETY RULES ABOUT USE AND OPERATION

- The operator of the machine (driver) must have competences and skills that are suitable to the type of work to be performed, and his/her conditions must be appropriate to perform the activity in a safe way.
- The operator must be suitably trained and documented about the use of the machine, and the first time the machine is used, (s)he must simulate some test manoeuvres to identify main controls and functions.
- During normal working conditions, the machine must be driven by a single operator (driver) in the tractor's driver seat. The operator is in charge of driving the machine and to operate the different controls to activate its functions.




-During normal working conditions, it is absolutely forbidden to transport people on the machine or make them get in to check its operation.

- The machine has been designed and manufactured in order to meet all operating conditions indicated by the Manufacturer. Tampering with any device in order to obtain a different performance from its original one may compromise people's health and safety and lead to economic losses.
- The machine must be used only for the purposes provided for by the Manufacturer. An improper use of the machine can endanger people's safety and lead to economic losses.
- Do not use the machine if the safety devices are not perfectly installed and efficient. If this requirement is not met, people's safety and health may be seriously compromised.
- Do not go on using the machine in case irregularities are detected. Immediately stop the machine, and then restart it only when the normal operating conditions have been restored.
- During the pick-up of the products, evaluate their typology (short, dry, etc.) and hold to the indications specified in the operation manual to avoid clogging.
- Prevent unauthorised persons, especially children, old people and domestic animals from approaching the operating area when the machine is used. If it is necessary, immediately stop the machine and make people leave hazardous areas.
- Do not leave the machine unattended when the tractor is running.
- Couple the machine to tractors whose category and features are suitable; they have to be equipped with pressurised cab in order to prevent the driver from being exposed to dust.
If the tractor is not equipped with a pressurised cab, use suitable personal protective devices (goggles, masks, etc.).



IDM-2172052400.pdf

–Connect the machine to the tractor’s towing bar in a way to prevent it from accidentally uncoupling during normal working conditions.



IDM-2172052300.pdf

–Connect the cardan shaft in a correct way and with perfectly efficient safety protections. The incorrect installation and inefficiency of safety protections cause the majority of accidents (even lethal accidents).

–To connect the cardan shaft, the PTO must be disengaged, tractor’s engine must be turned off and the ignition key must be removed and kept by the driver.

–First, connect the cardan to the splined shaft of the reduction gear in the machine, and then connect it to tractor PTO. Properly couple it to prevent the protections from rotating.

–Use only the cardan shaft supplied with the machine or rather use an original spare part. Do not use the shaft supplied with other machines.

If the cardan shaft supplied with the machine is equipped with the safety bolt and the latter has to be replaced, use an original spare part having the same features that are specified in the technical data table.


–Make sure that the cardan shaft complies with the laws in force about safety.

–Before activating the PTO, make sure that the cardan shaft is correctly installed, that the rotation direction and the maximum rate comply with machine working parameters.

Further information regarding the cardan shaft is shown in the manual issued by its manufacturer.


–Never activate the PTO when the tractor engine is turned off and the cardan shaft is connected. In case of accidental start-up of the engine, the operating conditions will not be suitable to guarantee the safety of the people who are close to the machine.

- Before operating the machine, check that all protection devices are correctly installed and in working order and that all connections (oil-pressure, electric, etc.) are performed in a suitable way. Furthermore, warning and information devices must be perfectly efficient and visible.
- Do not try to unblock the machine or remove the clogging when the tractor is running, but stop it in safe conditions with a deactivated power take-off, the motor OFF and the ignition key being disconnected.



- In case of steep soils, adapt the speed of the machine according to the slope and the stability of the soil.
- In case of soils whose slope can cause risks of sudden and uncontrolled movements of the bale, unload the bale crosswise to the slope. Use this precaution especially when the machine is equipped with the bale kicker.
- Use the machine with the personal protective devices that are specified in the manual and the ones that are provided for by the laws in force about safety at work.

SAFETY RULES ABOUT ROAD CIRCULATION




- The machine is approved for road use over the Italian national territory. In case of road circulation, the driver must check the pressure and the wearing condition of the tyres; furthermore, the driver must check that warning and information devices are perfectly efficient and visible. In case of road circulation, the driver must comply with the traffic regulations in force in the country where the machine is used and, furthermore, (s)he must suitably drive it to assure the safety of all other road users.
- Comply with the speed limits being provided for and adapt the speed according to the general conditions (busy road traffic, tortuous streets, etc.).

- Do not use the machine as a means to transport people or things.
During road use, the baling chamber must be closed and empty (without bale).
- Before road use, check that the cardan shaft is correctly connected to the power take-off, which must be disconnected and that the pick-up unit is lifted and locked in safe conditions.

SAFETY RULES ABOUT MAINTENANCE AND ADJUSTMENTS

- Keep the machine in maximum efficiency conditions and carry out the scheduled maintenance recommended by the Manufacturer. Good maintenance ensures the best performance, a longer work life and the constant maintenance of the safety requirements.
Good maintenance will allow, moreover, to avoid fire risks during the operative phases of the machine.
- Before performing any maintenance and adjustment intervention, activate all safety devices of the machine.
- Before performing any maintenance intervention in areas of the machine that are hazardous or not easily accessible, prearrange suitable safety conditions in compliance with the laws in force about occupational safety.



- Perform maintenance and adjustment operations with the machine placed in a level area; the wheels must be locked by using the specific supplied wedges, the power take-off must be deactivated, the motor OFF and the ignition key disconnected.**
- During adjustment and maintenance operations in the machine, use only the clothes and/or the personal protective devices that are specified by the Manufacturer and established by the laws in force about occupational safety.
- Replace worn components with original spare parts. Use oils and greases recommended by the manufacturer. This will ensure the perfect operation of the machine and the safety level required.
- Do not throw away any polluting material in the environment. Carry out their disposal in compliance with the relevant legislation in force.
- Only authorised personnel will have to perform extraordinary maintenance operations; the personnel will have to prearrange all necessary safety conditions and comply with the specified procedures.

Do not perform checks and adjustments when the machine is moving and with an operator being transported. This situation was not provided for when designing and manufacturing the machine.

SAFETY RULES FOR THE ENVIRONMENTAL IMPACT

- The Waste of Electrical and Electronic Equipment may contain dangerous substances with potentially harmful effects on the environment and on people. It is recommended to correctly dispose them.
- When the machine is dismantled, select all components according to their chemical characteristics and collect them separately in compliance with the relevant laws.
- With reference to the WEEE directive (Waste of Electrical and Electronic Equipment), during dismantling, the user must separate the electrical and the electronic components and dispose them in the appropriate authorized collection centres or give them back as they are to the seller, when a new purchase is made.



All the components, which must be separated and disposed of in a specific manner, are marked with a special mark.

- The unauthorized disposal of Waste of Electrical and Electronic Equipment (WEEE) is subject to fine according to sanctions regulated by the laws in force in the territory where the infraction has been verified.
- As implementation of the European directives (2002/95/CE, 2002/96/CE, 2003/108/CE) in the Italian territory, for example, a law decree (n. 151 dated July 25 2005) has been enacted, thus providing for an administrative fine of 2000÷5000.

DESCRIPTION OF SAFETY SIGNS

The figures represent the safety and information signals applied to the machine. The meaning of each signal is explained beside the machine.



General danger: carefully read the operator's manual prior to starting the machine operations. Observe the norms and the safety instructions during operation.



General danger: prior to carrying out maintenance or repair work, stop the motor and remove the ignition key.




General danger: prior to carrying out maintenance or repair work on the pick up unit, stop the motor and remove the ignition key.



General danger: lifting point with hook tool.



General danger: lifting point with fork tool.



Danger of body crushing: prior to intervening in zones of potential danger, within the machine and with the gate open, insert the safety block.



Danger of body crushing: prior to intervening in zones of potential danger, insert the safety block.



Danger of body crushing: when the motor of the tractor is running, stay clear of the zone where the gate opens.



Danger of body crushing: upload the bale in order to prevent the risk of sudden and uncontrolled movements (for example, in case of extremely steep soils).



Danger of body crushing: stay at a safe distance from the raised gate, if the safety block is not inserted.



Danger of body crushing: when the motor is running, stay clear of the articulations.



Danger of body crushing: when the lifter is in operation stay outside the working range of the three-point tool.



Danger of body crushing: prior to unhooking or parking the machine, put the wedges in place.



Danger of catching: do not go near any components of the pick-up, while the tractor's motor is running and the PTO is inserted.



Danger of catching: when the motor is running, do not open or remove the protections.



Danger of catching: when the motor is running, do not open or remove the protections.



Danger of catching: prior to starting the machine, close the safety protections.



Danger of catching: when the motor is running, do not open or remove the protections.



Danger of catching: when the motor is running, do not open or remove the protections.



Danger of shearing: remain far from the machines work range.



Danger of pouring out of fluids: avoid spills of fluids under pressure. For maintenance procedures, see the technical manual.



Danger of explosion: the hydraulic accumulators contain gas and oil under pressure. For their removal or repair, follow the instructions contained in the technical manual.



Danger of electrocution: remain at a sufficient distance from the electrical lines.



Danger of falling: do not stand on the platform or the steps when the machine is in operation.



No parking: it is forbidden to stop within the range of action of the machine.

Prevent unauthorised persons, especially children, old people and domestic animals from approaching the operating area when the machine is used. If it is necessary, immediately stop the machine and make people leave hazardous areas.



Perching not allowed: do not utilise the zone in which the signal is applied as a perch for reaching higher parts of the machine.




safety devices

**Page intentionally left
without information**

GENERAL DESCRIPTION OF THE MACHINE

- The variable chamber round baler is a towed machine, which was designed and manufactured for agricultural purposes and, more precisely, to pick windrows of different stem plants (fodders, straw, etc.), in order to press them into round bales.
- According to the different production needs, the machine can be set up with different versions and models (See "Technical Data").
- The electronic control system, which is positioned close to the driver's seat in the tractor, manages and enables work parameters (bale diameter, binding type, etc.), operating conditions and operation irregularities of the machine.
- The machine allows manufacturing "soft core" or "solid core" bales, with different density and diameter.
- Only one operator is requested on the tractor (driver) for the use and operation of the machine. The driver must meet the necessary requirements and be suitably trained by the dealer for the safe drive and use of the machine.
- The machine can pick different stem plants, such as straw, hay, and fodder to be ensiled, as well as poles (maize, soybean, Indian millet, etc.). For normal works, the machine must be towed by a tractor whose category and power are appropriate, and it must also be equipped with PTO to drive the main devices.
- The tractor must be equipped with couplings for PTO, electric and hydraulic systems.
- The tractor should be equipped with driver's seat pressurised cabin in order to prevent the driver from wearing personal protective devices (dust mask, noise-reduction headset, etc).

Main components




- **Transmission unit (A)**: it is mechanical type (with reduction gear and cardan shaft) and conveys motion to the main operating units of the machine by means of a kinematic mechanism that is formed by pinions and chains.
- **Cardan shaft (A1)**: the shaft that is supplied with the machine is homocinetic and can be equipped with a safety bolt.
The cardan shaft supplied with the machine complies with the provisions of the directives and standards in force about this matter.
- **Drawbar (B)**: it connects the machine to the tractor and its height can be adjusted to adapt to the towing eye of the tractor.
- **Pick-up unit (C)**: it picks the windrow product and conveys it into the feeding unit.
The machine, depending upon the conformation of the ground and the width of the windrow, may be equipped with a pick-up unit of various types.⁽¹⁾
The pick-up unit is equipped with a safety bolt , which, in case of product clogging, gets sheared to prevent damages to units or parts of the machine.
- **Product feeding unit (D)**: it transfers the product into the baling chamber.
The machine, depending upon the type of product to pick up, may be equipped with a feeding unit of various types. ⁽¹⁾
- **Baling chamber (E)**: it is "variable volume" type and creates the bale by means of belts (**E1**) and rollers.
- **Tightener unit (F)**: it tightens the belts (**E1**) of the baling chamber (**E**).
- **Net binder unit (G)**: it quickly binds the bale up to the edges, so that the bale becomes solid and compact. ⁽¹⁾
- **Twine binder unit (H)**: it binds the bale with spiral twine winding, so that the bale becomes solid and compact. ⁽¹⁾
- **Net or twine introduction device (L)**: it introduces the binding element into the baling chamber.
- **Centralized lubrication system (M)**: it automatically lubricates the transmission chains.
- **Electronic control system (N)**: it is used to display and set production parameters. ⁽¹⁾

(1) To know the features and the functionalities of the operator unit installed in the machine, see the relevant part.


OPERATION CYCLE

- The machine goes straight along the windrow; the pick-up unit takes the products, and then transports it into the feeding unit. The feed unit conveys the product into the baling chamber.




IDM-2172900201.pdf

- The baling process starts inside the baling chamber thanks to the operation of the belts. The tightener unit keeps the belts tightened to constantly adapt to the varying bale diameter.




IDM-2172900301.pdf

- When the bale achieves the set diameter, the electronic control system emits a sound signal to warn the operator that it is necessary to interrupt the forward movement of the tractor. According to the selected type of binding (twine, net or mixed) and the operating mode set in the electronic control system (manual or automatic), the binder unit starts the bale binding operation.



- At the end of the binding process, the electronic control system emits another sound signal to warn the operator that it is possible to open the tail gate for bale unloading. If the machine is equipped with the bale kicker, you can restart working without the need to perform any additional manoeuvre.



If the machine is not equipped with the bale kicker, the operator will have to move the machine backwards of about 4÷5 m, and then unload the bale. At the end of the unloading operation, in order to prevent the tail gate from bumping against the bale during the closing operation, the operator must take the machine back to the beginning of the windrow; the work can be continued by applying the specific procedures.

Caution
Precaution

In case of soils whose slope can cause risks of sudden and uncontrolled movements of the bale, unload the bale crosswise to the slope. Use this precaution especially when the machine is equipped with the bale kicker. If it is not possible to unload the bale in a safe way, transfer the machine into a suitable area, and then unload the bale.

IMPROPER USE

The use of the machine for operations that are different from the purposes being provided for by the manufacturer must be considered as IMPROPER USE.

- Do not circulate in public roads with machines that are not type-approved and not correctly prearranged to assure its own safety, as well as the safety of the other users of the street.
- Do not use the machine as a means to transport people or things.
- Do not couple the machine to tractors whose category and features are not suitable.
- Do not use the machine to pick up products that are different from the established ones.
- Do not use the machine to pick up the product (straw, hay, ensiled products and maize poles) if it has not been prepared in windrows.
- Replace the shorn "safety bolts" ONLY with original spare parts that comply with the provisions.

In case of improper use of the machine, the operator assumes the responsibilities (moral, civil and criminal) for the damages caused to people or things.

RESIDUAL RISKS

Even though the manufacturer complies with the laws in force and adopts the "code of practice", the listed residual risks still remain.

- Danger of lethal "whiplash" if the PTO is accidentally started during the connection of the cardan shaft, which is not performed according to the correct procedures and sequences.

Do not engage the cardan shaft when the engine of the tractor is on, the ignition key is engaged and the PTO is activated.

Engage the cardan shaft first to the PTO of the machine, and then to the PTO of the tractor.

- Danger of catching and dragging with serious consequences (even mortal) if the operator tries to unblock the machine without using the procedures that are described in the user and maintenance manual, and without using the relevant devices.

Do not try to remove product clogging in the machine when the engine of the tractor is on, the ignition key is engaged and the PTO is activated.

Product clogging removal operations must be performed according to the specific procedures (See booklet 4).


- If the operator uses the machine at speeds that are not suitable to the ground (steep slopes) and/or with slopes that exceed the maximum allowed levels, the machine may become unstable and/or capsize.

Do not use the machine in soils that are characterised by risks of instability and/or overturning, such as for example: close to ditches, precipices, loose soil, steep slopes, etc. If the aforesaid conditions are present, employ all necessary measures to prevent possible risks.

- Danger of running into people, animals or things during reverse motion, opening/closing of the tail gate and bale unloading caused by a reduced visibility from the driver's seat of the area behind the machine.
- Danger of contact between the upper limbs or parts of the body and parts of the machine during those maintenance operations in which it is necessary to perform some checks with machine devices being moving.
- Danger of fire if machine maintenance and check procedures are not performed correctly, especially if there is a bale (partial or complete) inside the baling chamber.
- Danger of catching into the cardan shaft if the protective devices are damaged or are not installed in a correct way.

AREAS OF DANGER

The figure illustrates the danger zones where no-one should be when the machine is in use. It is the operator's duty to keep such zones out of bounds; if necessary, (s)he should turn the engine off and clear out the danger zone.



NIGHT WORK

The machine can be used during night hours, too. The work in such conditions implies an increased number of risks. In order to avoid endangering the health and safety of people, all lighting devices that are installed in the tractor and in the machine must be effective and efficient.

If the work area conditions require it, you have to perform a preliminary inspection in order to identify hazardous areas (steep soils, closeness to precipices, etc.) and mark them adequately.



Caution Precaution

All adjustment, maintenance and check operations of the machine can be performed during night hours only if the safety and lighting conditions are suitable.

TECHNICAL DATA RV 4116 F**Table 1:** Technical data of the machine

Description	Unit of measurement	Model		
		RV 4116 FT	RV 4116 FN	RV 4116 FNT
Features of the machine				
Total length of the machine	mm	4480	4480	4480
Total width of the machine	mm	2470	2470	2470
Total height of the machine	mm	2700	2700	2700
Weight	kg	2600	2600	2660
Bale hourly output	n.	18÷35	18÷35	18÷35
Features of the tyres				
Dimensions of machine tyres		11.5/80-15"	11.5/80-15"	11.5/80-15"
inflation pressure	bar	2,5	2,5	2,5
Dimensions of machine tyres (optional)		a - 15.0/55-17" b - 19.0/45-17"	a - 15.0/55-17" b - 19.0/45-17"	a - 15.0/55-17" b - 19.0/45-17"
inflation pressure	bar	a - 2,5 b - 2,5	a - 2,5 b - 2,5	a - 2,5 b - 2,5
Dimensions of pick-up wheel tyres		16x6,50-8 6 PR	16x6,50-8 6 PR	16x6,50-8 6 PR
inflation pressure	bar	1,5	1,5	1,5
Tightening torque for machine wheel columns	Nm	310	310	310
Lubrication system				
Tank capacity	lt	2		
Lubrication type		Automatic lubrication		
Features of the baling chamber				
Rollers	n.	3	3	3
Belts	n.	5	5	5
Feeding unit				
Type		Simple feeder	Simple feeder	Simple feeder
Net binder unit				
Type		Electronic binder (Optional).	Electronic binder	Electronic binder
Twine binder unit				
Type		Electronic binder	Electronic binder (Optional).	Electronic binder
Quantity of twines	n.	2	2	2
Features of the net reel				
Maximum diameter of the reel	mm	320		
Maximum width of the reel	mm	1300		
Net type	gr/m	14÷18		
Features of the twine reel				
Maximum diameter of the reel	mm	250		
Maximum height of the reel	mm	240		

Table 1: Technical data of the machine

Description	Unit of measurement	Model		
		RV 4116 FT	RV 4116 FN	RV 4116 FNT
Twine type (synthetic)	m/kg	500÷1000		
Twine type (vegetal)	m/kg	200÷400		
Features of the bale				
Diameter	mm	600÷1650	600÷1650	600÷1650
Width	mm	1200	1200	1200
Max volume	m ³	2,5	2,5	2,5
Pick-up unit				
Type		"Large" pick-up	"Large" pick-up	"Large" pick-up
Maximum pick-up width	mm	2000 (1820 DIN standard).	2000 (1820 DIN standard).	2000 (1820 DIN standard).
Tines bars	n.	4	4	4
Pick-up tines (for each bar)	n.	28	28	28
Distance between pick-up tines	mm	60	60	60
Safety bolt		M8x40 UNI 5739 R=80 Kg/mm ² (8.8)		
Lubrication type		Lubrication from centralised system		
Tractor requirements				
Minimum power to the pto	CV (kW)	55 (38)	55 (38)	55 (38)
Recommended power to the pto	CV (kW)	64 (45)	64 (45)	64 (45)
PTO rotation rate	rpm	540	540	540
Splined profile of the PTO shaft		1"3/8 z=6		
Tow bar		Rotating, with "U" hook		
Diameter of towing coupling pivot of the tractor	mm	35 - 40 - 50		
Hydraulic system		N.1 single-acting control valve + N.1 double-acting control valve with floating position	N.1 single-acting control valve + N.1 double-acting control valve with floating position	N.1 single-acting control valve + N.1 double-acting control valve with floating position
Quick-release couplings for hydraulic system		ISO 7241-1 series "A", size 081/2; max. pressure 180 bar		
Electrical system		1 electric socket 3-poles 12 V 1 electric socket 7-poles 12 V		
Noise level				
sound level that is detected at the driver's seat	dbA	89	89	89
Cardan shaft				
Safety bolt		M8x60 UNI 5737 R=80 Kg/mm ² (8.8)	M8x60 UNI 5737 R=80 Kg/mm ² (8.8)	M8x60 UNI 5737 R=80 Kg/mm ² (8.8)
Torque limiter	Nm	-	-	-

TECHNICAL DATA RV 4116 R**Table 2:** Technical data of the machine

Description	Unit of measurement	Model		
		RV 4116 RT	RV 4116 RN	RV 4116 RNT
Features of the machine				
Total length of the machine	mm	4480	4480	4480
Total width of the machine	mm	2520	2520	2520
Total height of the machine	mm	2700	2700	2700
Weight	kg	2850	2850	2910
Bale hourly output	n.	18÷35	18÷35	18÷35
Features of the tyres				
Dimensions of machine tyres		15.0/55-17"	15.0/55-17"	15.0/55-17"
inflation pressure	bar	2,5	2,5	2,5
Dimensions of machine tyres (optional)		a - 19.0/45-17" b - 550/45-22.5"	a - 19.0/45-17" b - 550/45-22.5"	a - 19.0/45-17" b - 550/45-22.5"
inflation pressure	bar	a - 2,5 b - 2,5	a - 2,5 b - 2,5	a - 2,5 b - 2,5
Dimensions of pick-up wheel tyres		16x6,50-8 6 PR	16x6,50-8 6 PR	16x6,50-8 6 PR
inflation pressure	bar	1,5	1,5	1,5
Tightening torque for machine wheel columns	Nm	310	310	310
Lubrication system				
Tank capacity	lt	2		
Lubrication type		Automatic lubrication		
Features of the baling chamber				
Rollers	n.	3	3	3
Belts	n.	5	5	5
Feeding unit				
Type		Rotor	Rotor	Rotor
Net binder unit				
Type		Electronic binder (Optional).	Electronic binder	Electronic binder
Twine binder unit				
Type		Electronic binder	Electronic binder (Optional).	Electronic binder
Quantity of twines	n.	2	2	2
Features of the net reel				
Maximum diameter of the reel	mm	320		
Maximum width of the reel	mm	1300		
Net type	gr/m	14÷18		
Features of the twine reel				
Maximum diameter of the reel	mm	250		
Maximum height of the reel	mm	240		

Table 2: Technical data of the machine

Description	Unit of measurement	Model		
		RV 4116 RT	RV 4116 RN	RV 4116 RNT
Twine type (synthetic)	m/kg	500÷1000		
Twine type (vegetal)	m/kg	200÷400		
Features of the bale				
Diameter	mm	600÷1650	600÷1650	600÷1650
Width	mm	1200	1200	1200
Max volume	m ³	2,5	2,5	2,5
Pick-up unit				
Type		"Extra-large" pick-up	"Extra-large" pick-up	"Extra-large" pick-up
Maximum pick-up width	mm	2200 (2060 DIN standard).	2200 (2060 DIN standard).	2200 (2060 DIN standard).
Tines bars	n.	5	5	5
Pick-up tines (for each bar)	n.	32	32	32
Distance between pick-up tines	mm	60	60	60
Torque limiter		-		
Lubrication type		Lubrication from centralised system		
Tractor requirements				
Minimum power to the pto	CV (kW)	60 (45)	60 (45)	60 (45)
Recommended power to the pto	CV (kW)	70 (52)	70 (52)	70 (52)
PTO rotation rate	rpm	540	540	540
Splined profile of the PTO shaft		1"3/8 z=6		
Tow bar		Rotating, with "U" hook		
Diameter of towing coupling pivot of the tractor	mm	35 - 40 - 50		
Hydraulic system		N.1 single-acting control valve + N.1 double-acting control valve with floating position	N.1 single-acting control valve + N.1 double-acting control valve with floating position	N.1 single-acting control valve + N.1 double-acting control valve with floating position
Quick-release couplings for hydraulic system		ISO 7241-1 series "A", size 081/2; max. pressure 180 bar		
Electrical system		1 electric socket 3-poles 12 V 1 electric socket 7-poles 12 V		
Noise level				
sound level that is detected at the driver's seat	dbA	89	89	89
Cardan shaft				
Safety bolt		-	-	-
Torque limiter	Nm	2000	2000	2000

TECHNICAL DATA RV 4118 F**Table 3:** Technical data of the machine

Description	Unit of measurement	Model		
		RV 4118 FT	RV 4118 FN	RV 4118 FNT
Features of the machine				
Total length of the machine	mm	4480	4480	4480
Total width of the machine	mm	2470	2470	2470
Total height of the machine	mm	2780	2780	2780
Weight	kg	2800	2800	2860
Bale hourly output	n.	18÷35	18÷35	18÷35
Features of the tyres				
Dimensions of machine tyres		11.5/80-15"	11.5/80-15"	11.5/80-15"
inflation pressure	bar	2,5	2,5	2,5
Dimensions of machine tyres (optional)		a - 15.0/55-17" b - 19.0/45-17"	a - 15.0/55-17" b - 19.0/45-17"	a - 15.0/55-17" b - 19.0/45-17"
inflation pressure	bar	a - 2,5 b - 2,5	a - 2,5 b - 2,5	a - 2,5 b - 2,5
Dimensions of pick-up wheel tyres		16x6,50-8 6 PR	16x6,50-8 6 PR	16x6,50-8 6 PR
inflation pressure	bar	1,5	1,5	1,5
Tightening torque for machine wheel columns	Nm	310	310	310
Lubrication system				
Tank capacity	lt	2		
Lubrication type		Automatic lubrication		
Features of the baling chamber				
Rollers	n.	3	3	3
Belts	n.	5	5	5
Feeding unit				
Type		Simple feeder	Simple feeder	Simple feeder
Net binder unit				
Type		Electronic binder (Optional).	Electronic binder	Electronic binder
Twine binder unit				
Type		Electronic binder	Electronic binder (Optional).	Electronic binder
Quantity of twines	n.	2	2	2
Features of the net reel				
Maximum diameter of the reel	mm	320		
Maximum width of the reel	mm	1300		
Net type	gr/m	14÷18		
Features of the twine reel				
Maximum diameter of the reel	mm	250		

Table 3: Technical data of the machine

Description	Unit of measurement	Model		
		RV 4118 FT	RV 4118 FN	RV 4118 FNT
Maximum height of the reel	mm	240		
Twine type (synthetic)	m/kg	500÷1000		
Twine type (vegetal)	m/kg	200÷400		
Features of the bale				
Diameter	mm	600÷1800	600÷1800	600÷1800
Width	mm	1200	1200	1200
Max volume	m ³	3	3	3
Pick-up unit				
Type		"Large" pick-up	"Large" pick-up	"Large" pick-up
Maximum pick-up width	mm	2000 (1820 DIN standard).	2000 (1820 DIN standard).	2000 (1820 DIN standard).
Tines bars	n.	4	4	4
Pick-up tines (for each bar)	n.	28	28	28
Distance between pick-up tines	mm	60	60	60
Safety bolt		M8x40 UNI 5739 R=80 Kg/mm ² (8.8)		
Lubrication type		Lubrication from centralised system		
Tractor requirements				
Minimum power to the pto	CV (kW)	64 (45)	64 (45)	64 (45)
Recommended power to the pto	CV (kW)	70 (52)	70 (52)	70 (52)
PTO rotation rate	rpm	540	540	540
Splined profile of the PTO shaft		1"3/8 z=6		
Tow bar		Rotating, with "U" hook		
Diameter of towing coupling pivot of the tractor	mm	35 - 40 - 50		
Hydraulic system		N.1 single-acting control valve + N.1 double-acting control valve with floating position	N.1 single-acting control valve + N.1 double-acting control valve with floating position	N.1 single-acting control valve + N.1 double-acting control valve with floating position
Quick-release couplings for hydraulic system		ISO 7241-1 series "A", size 081/2; max. pressure 180 bar		
Electrical system		1 electric socket 3-poles 12 V 1 electric socket 7-poles 12 V		
Noise level				
sound level that is detected at the driver's seat	dbA	89	89	89
Cardan shaft				
Safety bolt		M8x60 UNI 5737 R=80 Kg/mm ² (8.8)	M8x60 UNI 5737 R=80 Kg/mm ² (8.8)	M8x60 UNI 5737 R=80 Kg/mm ² (8.8)
Torque limiter	Nm	-	-	-

TECHNICAL DATA RV 4118 R**Table 4:** Technical data of the machine

Description	Unit of measurement	Model		
		RV 4118 RT	RV 4118 RN	RV 4118 RNT
Features of the machine				
Total length of the machine	mm	4480	4480	4480
Total width of the machine	mm	2470	2470	2470
Total height of the machine	mm	2780	2780	2780
Weight	kg	3050	3050	3110
Bale hourly output	n.	18÷35	18÷35	18÷35
Features of the tyres				
Dimensions of machine tyres		15.0/55-17"	15.0/55-17"	15.0/55-17"
inflation pressure	bar	2,5	2,5	2,5
Dimensions of machine tyres (optional)		a - 19.0/45-17" b - 550/45-22.5"	a - 19.0/45-17" b - 550/45-22.5"	a - 19.0/45-17" b - 550/45-22.5"
inflation pressure	bar	a - 2,5 b - 2,5	a - 2,5 b - 2,5	a - 2,5 b - 2,5
Dimensions of pick-up wheel tyres		16x6,50-8 6 PR	16x6,50-8 6 PR	16x6,50-8 6 PR
inflation pressure	bar	1,5	1,5	1,5
Tightening torque for machine wheel columns	Nm	310	310	310
Lubrication system				
Tank capacity	lt	2		
Lubrication type		Automatic lubrication		
Features of the baling chamber				
Rollers	n.	3	3	3
Belts	n.	5	5	5
Feeding unit				
Type		Rotor	Rotor	Rotor
Net binder unit				
Type		Electronic binder (Optional).	Electronic binder	Electronic binder
Twine binder unit				
Type		Electronic binder	Electronic binder (Optional).	Electronic binder
Quantity of twines	n.	2	2	2
Features of the net reel				
Maximum diameter of the reel	mm	320		
Maximum width of the reel	mm	1300		
Net type	gr/m	14÷18		
Features of the twine reel				
Maximum diameter of the reel	mm	250		

Table 4: Technical data of the machine

Description	Unit of measurement	Model		
		RV 4118 RT	RV 4118 RN	RV 4118 RNT
Maximum height of the reel	mm	240		
Twine type (synthetic)	m/kg	500÷1000		
Twine type (vegetal)	m/kg	200÷400		
Features of the bale				
Diameter	mm	600÷1800	600÷1800	600÷1800
Width	mm	1200	1200	1200
Max volume	m ³	3	3	3
Pick-up unit				
Type		"Extra-large" pick-up	"Extra-large" pick-up	"Extra-large" pick-up
Maximum pick-up width	mm	2200 (2060 DIN standard).	2200 (2060 DIN standard).	2200 (2060 DIN standard).
Tines bars	n.	5	5	5
Pick-up tines (for each bar)	n.	32	32	32
Distance between pick-up tines	mm	60	60	60
Torque limiter		-		
Lubrication type		Lubrication from centralised system		
Tractor requirements				
Minimum power to the pto	CV (kW)	70 (52)	70 (52)	70 (52)
Recommended power to the pto	CV (kW)	75 (56)	75 (56)	75 (56)
PTO rotation rate	rpm	540	540	540
Splined profile of the PTO shaft		1"3/8 z=6		
Tow bar		Rotating, with "U" hook		
Diameter of towing coupling pivot of the tractor	mm	35 - 40 - 50		
Hydraulic system		N.1 single-acting control valve + N.1 double-acting control valve with floating position	N.1 single-acting control valve + N.1 double-acting control valve with floating position	N.1 single-acting control valve + N.1 double-acting control valve with floating position
Quick-release couplings for hydraulic system		ISO 7241-1 series "A", size 081/2; max. pressure 180 bar		
Electrical system		1 electric socket 3-poles 12 V 1 electric socket 7-poles 12 V		
Noise level				
sound level that is detected at the driver's seat	dbA	89	89	89
Cardan shaft				
Safety bolt		-	-	-
Torque limiter	Nm	2000	2000	2000


ALLOWABLE SLOPES

The image shows the maximum permissible slope in hard grounds, free from hollows and obstacles, with the machine in running order.

! Danger Warning

Danger of overturning: do not use the machine in soils whose slope exceeds the allowed limit or in the presence of other hazards (rises, hollows, etc.), which could limit the stability of the machine.

In case of steep soils, adapt the speed of the machine according to the slope and the stability of the soil.




EQUIPMENT

The following equipment is supplied with the machine.

- **Tool for product clogging removal (A):** it is a safety device that is used to remove the blockages and/or clogging in the zone of the pick-up unit and/or of the feeding unit (SIMPLE FEEDER).
- **Tool for product clogging removal (A1):** it is a safety device that is used to remove the blockages and/or clogging in the zone of the pick-up unit and/or of the feeding unit (ROTOR).
- **Pivot (B):** used for facilitating the mounting of the safety shear pin of the pick-up unit.
- **Safety bolt of the pick-up unit (C):** in case of product clogging, it gets sheared to prevent damages to assemblies or parts of the machine (Only for narrow or wide pick-up unit).
- **"Double feeder" feeding unit safety bolt (D):** in case of flooding, it must be shorn to prevent damages to units or parts of the machine.
- **Cardan shaft safety bolt (E):** in case of flooding, it must be shorn to prevent damages to the cardan shaft or parts of the machine.

Replace the shorn "safety bolts" ONLY with original spare parts that comply with the provisions.

- **Socket (F)**: it is 3 pole and must be installed on the tractor if the latter is not equipped with a socket.
- **Bar (G)**: it is used during the repairs of the rollers in the baling chamber.
- **Bar (H)**: it is used to introduce the twine into the twine guides.



IDM-48300400100.pdf


FITTINGS ON DEMAND

The machine can be equipped with some fittings, upon demand in the order or later.

Important

The mounting of the accessories, when requested after the purchase of the machine, has to be carried out by personnel with precise technical competency, in repair shops that are adequately equipped and authorised by the manufacturer.

Whoever carries out the installation of an accessory should issue a document that certifies that the mounting has been carried out in a repair shop that has been authorised by the manufacturer.



The listed accessories can be installed ONLY in the models of machines that are built in that way by the manufacturer.

DO NOT attempt to tamper with the accessories to adapt them to models of machines that are not built for it and/or to obtain performance that is different from what is allowed.

- **Bale kicker (A):** it is used to move the bale away from the machine during the unloading operation. This way, you can close the tail gate without the need to perform additional manoeuvres (forward and backward movements) to restart the pick-up operation from the point in which it was interrupted.

Caution Precaution

In case of soils whose slope can cause risks of sudden and uncontrolled movements of the bale, unload the bale crosswise to the slope. Use this precaution especially when the machine is equipped with the bale kicker.

If it is not possible to unload the bale in a safe way, transfer the machine into a suitable area, and then unload the bale.

- **Straw baler device (B):** it is used to compress dry, short and friable products (for example, straw). It is particularly suitable when the pick up is performed in the hottest hours and/or seasons.


Important

Do not utilise the device to compress damp products.

- **"Brakes" kit:** it is pneumatically or hydraulically controlled, and improves the braking ability of the machine.
- **Cardan shaft with pawl-type torque limiter:** homocinetic, in case of clogging and/or flooding of the machine, the movement will disconnect.

SAFETY DEVICES


- **Cardan shaft (A)**: the shaft that is supplied with the machine is constant-velocity type and can be equipped either with a safety bolt or with a pawl-type torque limiter. With cardan shaft equipped with pawl-type torque limiter, in case of clogging and/or flooding of the machine, the movement will disconnect. With cardan shaft equipped with safety bolt, in case of clogging and/or flooding of the machine, the bolt will be shorn to interrupt the movement.



- **Cock (B)**: it is used to lock the tail gate in "open" position, so that the maintenance works inside the baling chamber can be carried out in safe conditions.



- **Fixed guard (C)**: it prevents the access to the moving devices of the machine. It can be opened only by means of an intentional action and with the aid of a tool.




- **Wheel chocks (D)**: they are used to prevent accidental displacements when the machine is parked and uncoupled from the tractor.
- **Support (E)**: it supports the cardan shaft and prevents its protections from breaking when it is disengaged from the tractor PTO.
- **Support leg (F)**: it keeps the drawbar of the machine in position when the machine is uncoupled from the tractor, and then makes its coupling easier.
- **Cock (G)**: it is used to lock the pick-up unit in "lifted" position, so that the transfer of the machine (during road use) can be carried out in safe conditions.
- **Unflooding tool (H)**: it is used to remove the clogging and/or the flooding in the area of the pick-up unit and/or of the feeding unit.

IDM-4830100800.pdf

- **Safety lock (L):** it is used to deactivate the cutter mechanism of the net binder unit in order to perform maintenance works in safe conditions.
- **Safety bolt of the pick-up unit (M):** in case of product clogging, it gets sheared to prevent damages to assemblies or parts of the machine (Only for narrow or wide pick-up unit).
- **Safety bolt of feeding unit with "simple feeder" (N):** in case of flooding, it must be shorn to prevent damages to units or parts of the machine.

Replace the shorn "safety bolts" ONLY with original spare parts that comply with the provisions.




IDM-483-004-00700.pdf

OIL-PRESSURE DEVICES

The list shows the description and the functionality only of some hydraulic devices.

For further details, see the booklets about the functional assemblies that are installed in the machine in paragraph "Oil-pressure devices".

- **Hydraulic cylinder (A):** it is single acting type; furthermore, it opens and closes the tail gate.
- **Hydraulic cylinder (B):** it drives the belt tightener to create a bale with the density that was set by means of the electronic control system.
- **Maximum pressure valve (C):** it is used to control the maximum working pressure of the tightener unit, and it calibrated by means of the electronic control system.




IDM-21722608000.pdf

ELECTRONIC AND ELECTRIC DEVICES

The list shows the description and the functionality only of some electric and electronic devices.

For further details, see the booklets about the functional assemblies that are installed in the machine in paragraph "Electronic and electric devices".

- **Secondary electronic control unit ECU (A):** manages the processes of operation of all the mechanisms installed on the machine (feeding unit, binding unit, etc.).
- **Electric motor (B):** it drives the net/twine introduction device.
- **3-pole plug (C):** it is used to connect the electric system of the binder unit to the tractor.
- **Sensor (D):** it detects the position of the hooks to close the tail gate.
- **Potentiometer (E):** it detects an excessive accumulation of product on the right side of the bale being pressed. The information is shown on the display of the electronic control system, so that the operator can modify the trajectory of the tractor.
- **Potentiometer (F):** it detects an excessive accumulation of product on the left side of the bale being pressed. The information is shown on the display of the electronic control system, so that the operator can modify the trajectory of the tractor.
- **Potentiometer (G):** it detects the diameter achieved by the bale.
- **Sensor (S2):** detects the position of the wire/net inserting device (front end of stroke), enables the stop of the electric motor (B) and resets the system




POSITION OF INFORMATION AND SAFETY PLATES

The figure shows the location of all safety plates, while their meaning is explained in booklet 1.

Important

Make sure that all plates are legible. If they are not, clean or replace, if necessary, ensuring the new ones are placed in the original position.



IDM-21720307800.pdf

INSTRUCTIONS FOR HANDLING AND LOADING

Important

Perform handling and loading operations by complying with the information supplied by the manufacturer, which is to be found in the machine and in user instructions. The people who are authorised to perform these operations, if necessary, will have to establish a "safety plan" to protect the safety of directly involved people.

PACKING AND UNPACKING


Depending on the destination, loading and transport can be carried out with different means.

The machine is shipped without packaging, except for some components.

- **Electronic control system (A):** it is packed into a box, which is placed into the reel-holding container (twine).
- **Cardan shaft (B):** it is packed into a box, which is fastened to a part of the machine.

Important

Upon receipt, check that the machine and its components are not damaged. In case of damages or lack of some parts, call the manufacturer or the local dealer to agree upon the procedures to be used.



LOADING AND UNLOADING

The machine can be loaded on the means of transport in different ways.

- Loading of the machine by using the tractor
- Loading of the machine by using a hook-type lifting device


Caution **Precaution**

The personnel in charge of loading, unloading and handling the machine must be competent and skilled according to the specific sector and must be in command of the means to be used.

Loading of the machine by using the tractor

Follow the instructions.

1. Move the tractor backwards until approaching and aligning the towing eye (A).
2. Adapt the height of the drawbar to the height of the towing hitch (See "How to set the height of the drawbar").
3. Stop the engine, apply the parking brake and disengage the ignition key.
4. Insert the hitch pin (B) and its locking pin (C).
5. Remove the locking pin (D1) and the hitch pin (D), lift the leg, and then fasten it again.
6. Lift the pick-up unit, and then lock it in "lifted" position by using the specific cock.




IDM-21722/01200.pdf

7. Load the machine on the means of transport, as shown in the figure.


Use ramps with suitable gradient and loading capacity.

8. Remove the locking pin (D1) and the hitch pin (D), lower the leg, and then re-introduce the hitch pin with the plug.
9. Remove the locking pin (C) and the hitch pin (B) to disengage the tractor from the machine.



720303400.tif

10. Suitably fasten the machine to the means of transport by means of ropes and chocks (see figure).




IDM-21722/01300.pdf

Loading of the machine by using a hook-type lifting device

Follow the instructions.

1. Visually control that the locking hooks of the tail gate are completely and correctly closed.
2. Prearrange a hook-type lifting device with suitable capacity, and then connect it to the machine by means of the specific ropes (see figure).
3. Slowly lift the machine, and then handle it with extreme care to prevent dangerous swinging.
4. Suitably fasten the machine to the means of transport by means of ropes and chocks.



MACHINE-TRACTOR COMBINATION

- When receiving the machine, you must check the relevant category and the features of the tractor to which it must be coupled, so that you can assure its stability and correct operation.
- After having checked the features of the tractor, you must adapt the height of the drawbar and the length of the cardan shaft (See "How to set the height of the drawbar" - "How to set the length of the cardan shaft").
- The length of the cardan shaft supplied with the machine meets any type of machine-tractor combination. The operator has the duty to cut the cardan shaft in a correct way.

The cardan shaft must be long enough so that it does not jam at its minimum extension or slip out at maximum extension.

i Important


The cardan shaft must be equipped with a constant-velocity joint. Consult the manufacturer's manual for further details concerning the cardan shaft.

HOW TO SET THE HEIGHT OF THE DRAWBAR

You can set the height of the drawbar according to the type of tractor towing.

The standard heights of the towing eye in the tractors equal 450÷500 mm or 900÷1000 mm.

- **Height 450÷500 mm:** the drawbar must be fastened in the hole (I) by using the screw (C).
- **Height 900÷1000 mm:** the drawbar must be fastened in the hole (II) by using the screw (C).




To modify the height of the drawbar, follow the instructions.

1. Fasten the drawbar by using a lifting device (lifting beam) with a suitable capacity.
2. Loosen screws (A).
3. Unscrew the nuts (B), and then remove the screws (C).
4. Lift or lower the drawbar (D) until aligning the hole (I) or the hole (II).
5. Introduce and tighten the screws (C).
6. Tighten screws (A).
7. Remove the lifting device.




Important

If machine is equipped with tyres of size 500/50-17" - 550/45-22.5", holes (E) can be used to fasten drawbar (D).



8. Adjust the support (G) so that the eye of the drawbar is at the same height of the towing eye of the tractor.



9. Unscrew the nuts (H), and then remove the screws (L).



Important

One screw (L) must be left inside in order to use it as fulcrum for the eyelet, and thus make operations easier.


10. Place the eyelet (M) in horizontal position.

11. Introduce and tighten the screws (L).



Important

At the end of the operation, check that the locking screws are correctly tightened to prevent the risk of detachment between the drawbar and the eye.



HOW TO SET THE LENGTH OF THE CARDAN SHAFT


Follow the instructions.

1. Check the length of the cardan shaft only after having decided the tractor to which the machine has to be coupled to.

The cardan shaft must be long enough so that it does not jam at its minimum extension or slip out at maximum extension.

2. Couple the machine to the tractor without assembling the cardan shaft (See "How to couple the machine to the tractor").

3. Steer the tractor of 80° with respect to the machine.
4. Make sure tractor PTO is disengaged.
5. Stop the engine, apply the parking brake and disengage the ignition key.
6. Measure the distance (X) between tractor PTO and the connection point of the cardan shaft in the machine.




7. Measure the length (Y) of the cardan shaft.

! Important

The length (Y) of the cardan shaft (completely closed) must be smaller than 10 cm at the distance (X). If not so, cut the exceeding part from the side of the "female" hose and on the side of the "male" hose. Cut the protective hoses in the same way.

8. After having cut the exceeding part, remove burrs and cutting debris.
9. Carefully lubricate "male" and "female" hoses, and then assemble them to re-create the cardan shaft.



- Introduce the cardan shaft (A) into the splined shaft of the reduction gear (B) in the machine.


! Danger Warning

The cardan shaft must be connected first to machine PTO, and then to tractor PTO. This allows preventing a lethal "whiplash" in case of tractor PTO unexpected start.

The constant-velocity joint of the cardan shaft must direct towards tractor PTO.

- Connect the safety chains of the protections: one to a component of the machine and the other to a component of the tractor.

- Perform a test to check that the length of the cardan shaft is suitable not to "stick" in the condition of minimum extension or not to "remove" in the condition of maximum extension.



i Important

Consult the manufacturer's manual for further details concerning the cardan shaft.

INSTRUCTIONS FOR USE AND OPERATION

The incidence of accidents that are caused by the use of machines depends on many factors, which cannot be prevented and controlled all the times. Some accidents can depend on unforeseeable environmental factors, while others mainly depend on the conduct of the operator.

Besides being authorised and properly documented, if necessary, the operator must simulate some manoeuvres to identify the main functions and controls when using the machine for the first time. Before usage, the operator must check that the safety devices are perfectly installed and effective. Besides undertaking to meet the aforesaid requirements, the operator must apply all safety standards in force.

The operator must read and understand the entire content of the user manual in order to know the controls and all details about the operation of the machine.

The user manual must be kept in a well known place, which can be easily accessed; this way, the manual is always at disposal when you have to read it.

Even though the machine was designed and manufactured to work in hard environmental conditions, you have to carry out scheduled maintenance interventions. Correct maintenance will allow achieving the best performance, a longer duration of work and a constant preservation of safety requirements.

To improve the safety conditions when the machine is working, besides personal experience and knowledge of all details about safety, you have to consider the reported instructions and recommendations, as well.

- Check that the cardan shaft is correctly installed; furthermore, all protections must be undamaged and effective.

The cardan shaft must be connected first to machine PTO, and then to tractor PTO. This allows preventing a lethal "whiplash" in case of tractor PTO unexpected start.

- Never use the cardan shaft as a support leg in order to perform any type of intervention in the machine.
- Always deactivate the PTO to stop the functions of the machine during excessive steering and transfer operations, especially during road circulation.
- Periodically check the tightening of the fastening screws in the main components (drawbar, towing eye, wheels, and wheel axes), the wear conditions and the pressure of the tyres.
- Check that the oil-pressure system feeding hoses are undamaged: there must be no oil leaks.
- Check the working area in order to assess the most suitable conditions (slope, roughness of the ground, etc.) to operate in a safe way.
- Check that all lighting devices being installed in the machine and in the tractor are effective and efficient in order to be able to operate even in reduced visibility conditions, at night time and during road use.
- Do not try to remove clogging when the machine is running: remove product clogging only after having stopped the machine in safe conditions.

- In case of collision against foreign bodies, stop the machine and switch off the tractor motor in safe conditions; after that, check the suffered damages and perform the necessary repairs.
- Prevent strangers from approaching the working area when the machine is in use. Should it become necessary, stop it immediately and make the people found in the risk area move away.

HOW TO COUPLE THE MACHINE TO THE TRACTOR

Follow the instructions.

1. When receiving the machine, you must check the relevant category and the features of the tractor to which it must be coupled, so that you can assure its stability and correct operation.


! Danger Warning

After having prearranged the necessary safety measures, only an operator must perform the operations to couple the machine from the tractor.

2. Remove the safety pin and the pivot (**B**) from the towing eye of the tractor.
3. Reverse the tractor until the towing hitch lines up with the eyelet (**A**).
4. Adapt the height of the drawbar to the height of the towing hitch (See "How to set the height of the drawbar").
5. Adapt the length of the cardan shaft supplied with the machine.
See "How to set the length of the cardan shaft"

How to connect the towing eye to the eye of the machine

1. Stop the engine, apply the parking brake and disengage the ignition key.
2. Insert the hitch pin (**B**) and its locking pin (**C**).
3. Remove the locking pin (**D1**) and the hitch pin (**D**), lift the leg, and then fasten it again.



Cardan shaft connection

1. Make sure tractor PTO is disengaged.
2. Check that the connection of the cardan shaft and of the tractor PTO are undamaged. Clean them in a thorough way, and then lubricate them with grease.
3. Connect the cardan shaft to the tractor PTO.


Danger **Warning**

The cardan shaft must be connected first to machine PTO, and then to tractor PTO. This allows preventing a lethal "whiplash" in case of tractor PTO unexpected start.
The constant-velocity joint of the cardan shaft must direct towards tractor PTO.

4. Connect the safety chains of the protections: one to a component of the machine and the other to a component of the tractor.

How to connect the oil-pressure system

1. Thoroughly clean the quick couplings.
2. Connect the hoses (A-B) to the couplings of the double acting control valve in the tractor.
The hoses (A-B) connect the tail gate opening/closing hydraulic system and the bale density hydraulic system.
3. Connect the hose (C) to the couplings of the single acting control valve in the tractor.
The tube (C) connects the hydraulic system of the pick-up/feeding devices.



IDM-21722001000.pdf

i Important

Use only original quick couplings that assure a correct connection. Do not use "push-pull" type quick couplings.

How to connect the electric system


1. Connect the cable (E) that feeds electricity to the warning devices.
2. Connect the cable (F) that feeds electricity to the binders.

i Important

If the tractor is not equipped with an electric socket for the binders, an expert operator will have to install the socket that is supplied in the standard equipment. The socket must be protected by means of a 20 A fuse.

When connecting the feeding systems, prevent the cables and/or the hoses from being twisted.


The terminal boards (+ and -) of the 3-pole socket must be directly connected to pole (+) of the battery, through a cable of at least 5 mm² section.



IDM-2172102000.pdf

How to connect the electronic control system

1. Install the electronic control system (G) (complete with support (H)) inside the tractor cab.
2. Connect the plug (L) to the socket (M) of the main electric cable of the machine.



DM-21723004200.pdf

HOW TO UNCOUPLE THE MACHINE FROM THE TRACTOR


Follow the instructions.

1. Stop the engine, apply the parking brake and disengage the ignition key.

! Important

Disconnect the machine in a level and stable area that can be accessed only by authorised operators, in a way not to create obstacles. The re-connection of the machine to the tractor will be easier if the disconnection is performed in such a way as to always assure the height of the eye from the ground.

2. Introduce the safety wedges (A).
3. Disengage the power cables.
4. Disengage the electronic control system.
5. Disengage the hoses of the oil-pressure system from the quick couplings.
6. Connect the rapid hitches to the specific support (B) to avoid damage and the introduction of foreign matter.
7. Wind the electric cables and the hydraulic hoses, and then hang them on the specific support (B).



IDM-48300101000.pdf

! Important


Prevent the cables and/or the hoses from being twisted.

8. Disconnect the chain from the cardan shaft (tractor side).
9. Disconnect the cardan shaft from the tractor, and then position it on the support (C).


! Danger Warning

The cardan shaft must be disengaged only from the tractor PTO.

10. Remove the locking pin (**D1**) and the hitch pin (**D**), lower the leg, and then re-introduce the hitch pin with the plug.
11. Adjust the height of the support leg (**E**) using the handle (**F**).




12. Remove the locking pin (**G1**) and the hitch pin (**G**) to disengage the tractor from the machine.
13. Slowly move the tractor forward in order to uncouple it from the machine.



HOW TO OPEN THE GUARDS

Follow the instructions.

1. Stop the engine, apply the parking brake and disengage the ignition key.
2. Turn the screw **(A)** to unblock the guard.
3. Act on the lever **(B)** to unhook the guard and raise it.
4. To carry out closing, lower the guard until hooking it into the specific blocking devices (correct closure takes place when one hears the mechanical release and when the guards stay blocked even should one attempt to pull on them manually).



Danger **Warning**

Before using the machine, make sure that the guards are perfectly installed and that both blocking devices are properly hooked.

INSTRUCTIONS AND SUGGESTIONS FOR USE

Before operating the machine, perform some preliminary checks in order to assure the performances of the machine.

- Set the diameter, the density of the bale and the binding parameters according to the type of product to be baled (See "Electronic control system").
- Check that the machine is supplied with a sufficient number of net reels. If not so, provide for them (See "Net binder unit (electronic)").
- Check that the machine is supplied with a sufficient number of twine reels. If not so, provide for them (See "Twine binder unit (electronic)").

To better exploit the potential of the machine and obtain good bale pressing, follow the listed instructions.

- **Bales that are uniform and correctly bound:** to obtain bales with these features, follow the direction instructions displayed by the LEDs in the electronic control system, then adapt the trajectory and the forward speed of the machine according to the operating conditions.
- **Products that are not much dry:** during the pick-up of products with these features, check that in the upper part of the machine there are no product leakages. If not so, point the trajectory of the tractor to the opposite part compared to the product leakage area.
- **Short and/or dry products:** during the pick up of products with these features, reduce the speed of the power take-off and increase the forward speed to prevent flooding.


The quality of the produced bales also depends on the type of windrow (dimensions, humidity, type of product, etc.), some features of which are shown in the list.

Dimensions of the windrow


- Width 1÷1,1 (m)
- Height 0,3÷0,4 (m)

Humidity


- HAY: percentage of humidity ≈20%
- SILAGE: percentage of humidity ≈40÷55%



- **Windrow prepared in a correct way:** keep a straight trajectory, as shown in the picture.



- **Narrow windrow:** apply the trajectory that is shown in the picture to uniformly feed the baling chamber.



At the end of the checks, act as specified.

1. Position the machine in the windrow.
2. Adjust the pick-up unit (See the "Pick-up unit").
3. Adapt the rate of the tractor so that the rate of the power take-off approaches 540 rev/min as much as possible.
4. Start the product pick-up operation.

- Interrupt the forward movement of the tractor when the electronic control system emits a sound signal to warn that the bale has reached the set diameter.

The binder unit starts the bale binding operation (net, twine or mixed).


If the binding is net type, during this operation, it is advisable to keep the rate of the power take-off at 400÷450 rev/min.

At the end of the binding process, the electronic control system emits another sound signal to warn the operator that it is possible to open the tail gate for bale unloading.

- Make sure that there are no people and/or obstacles within the range of action of the tail gate and in the bale unloading area.

- Adjust the lever (A) of the double-acting control valve with floating position, into the position 1 and do not release it before the completion of the bale unloading operation.


In case of soils whose slope can cause risks of sudden and uncontrolled movements of the bale, unload the bale crosswise to the slope. Use this precaution especially when the machine is equipped with the bale kicker.



A bale can be unloaded with one of the listed modes.

Machine "without bale kicker" (standard)

- During the binding operation, make the machine go backwards by 4÷5 m into the area where the bale will be unloaded. This operation will allow making up for time.
- Unload the bale and make the machine go forward up to the beginning of the windrow. During the forwarding movement, adjust the lever (A) in position 2 to close the tail gate back.



3. Release the lever **(A)** when the pressure signalled in the pressure gauge **(C)** starts to increase. It means that the bale density device has reached the set working pressure.

 **Caution**
Precaution

If the electronic control system warns that the tail gate has not closed correctly, place lever (A) again in position 2, and then repeat the tail gate closing operation.

4. Adjust the lever **(A)** in position **3** (floating position) until the electronic control system signals that the machine is correctly closed and ready for the following baling operation; keep it in the position for the entire duration of the bale pressing operation.

Machine "with bale kicker" (optional)

When the bale kicker is installed, the bale unloading operations (opening and closing of the tail gate) must be carried out directly in the point where the bale has been completed, without further additional manoeuvres.

1. Adjust the lever **(A)** in position **2** to close the tail gate back.
2. Release the lever **(A)** when the pressure signalled in the pressure gauge **(C)** starts to increase. It means that the bale density device has reached the set working pressure.

 **Caution**
Precaution

If the electronic control system warns that the tail gate has not closed correctly, place lever (A) again in position 2, and then repeat the tail gate closing operation.

3. Adjust the lever **(A)** in position **3** (floating position) until the electronic control system signals that the machine is correctly closed and ready for the following baling operation; keep it in the position for the entire duration of the bale pressing operation.

HOW TO SET BALE DIAMETER

To perform bale diameter setting, the tractor must be stopped with engine on, the parking brake must be applied and the PTO must be disengaged.

Bale diameter must be set by means of the electronic control system, which can also display the increase during pressing (See "Electronic control system").

HOW TO SET BALE DENSITY

Bale density depends on the tension of the belts in the baling chamber, and it must be set according to the type of product to be baled, the weight of the bale and the speed of the forward movement of the machine.

The bigger the value of the set working pressure, the bigger the bale density.

 **Caution**
Precaution


A working pressure that exceeds the maximum recommended values can cause damages to the machine, while an insufficient working pressure will create unstable and defective bales.

The table specifies the recommended pressure values according to the different types of product.

Table 5: recommended working pressures


Type of product	Working pressures (bar)
Straw	160÷230
Hay	80÷180
Ensiled product	50÷150

The values of the core diameter (**F**) and of the external diameter (**G**) can be selected on the control unit (See "Electronic control system"). The pressure / density in the core area (**F**) and in the external area (**G**) can be activated (**ON**) or deactivated (**OFF**) according to the type of product and / or requirements of the user (See "Electronic control system").



To establish bale density, follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the machine; the engine of the tractor must be on and the parking brake must be applied.
3. Place lever (**A**) of the hydraulic control valve in the tractor in position 1 to open the tail gate.
4. Adjust the lever (**A**) of the tractor hydraulic control valve into the position 2 in order to close the tail gate and keep it in position until the pressure displayed on the pressure gauge (**B**) reaches the set value. If the value that is detected in the manometer is not suitable, you will have to adjust the working pressure of the valve (**C**).
5. Stop the engine, apply the parking brake and disengage the ignition key.
6. To adjust the working pressure of the valve, open the door (**D**).



 Important

Since the valve is not equipped with reference notches that allow its adjustment to the selected value, you have to repeat the tail gate opening and closing procedures in order to adjust it properly.

7. To increase or reduce the working pressure, use the ring nut **(E)** in the valve.

 **Important**

The bigger the value of the set working pressure, the bigger the bale density.

If valve pressure is calibrated at a value that is higher than the maximum working pressure of the tractor, the manometer specifies the value of the latter.

8. Start the engine of the tractor from the driver's seat.
9. Set the minimum value of the bale diameter by means of the electronic control system; when this value is reached, the operating pressure set on the valve operates.

ROAD CIRCULATION

Road circulation is allowed only for type-approved machines, which are towed by a tractor with suitable features and category.

The driver of the tractor, which tows the machine, must comply with the requirements that are established by the laws in force.

Before using the machine in public roads, check that its conditions are suitable (non-worn tyres and with suitable pressure, efficient lighting and signalling devices, compliant documents, etc.) in order to comply with the rules of the road in force.


To improve safety conditions, besides personal experience, you have also to consider the reported instructions and suggestions.

- Unload the bale from the machine.
- Make sure the tail gate is closed in a complete and correct way.
- Make sure that the machine is correctly coupled to the tractor.
- Lift the pick-up unit, and then lock it by using the specific chain.
- Close the cock of the oil-pressure circuit that drives the pick-up.
- block the parts which could cause sudden unexpected movements.
- Clean the machine from remains of the picked product to prevent them from being spread along the path.
- Check that all road signalling devices are perfectly efficient and visible.
- Evaluate the wearing condition and the pressure of the tyres.
- Make sure tractor PTO is disengaged.
- Drive carefully, and in detail, reduce the speed in case of irregular soils. Curve carefully not to compromise the stability of the machine.
- Every adjustment, except when it is expressly specified, must be performed with disengaged PTO, and tractor engine off. Furthermore, the ignition key must be disengaged and kept by the driver.
- The personnel that are authorised to perform the adjustments must comply with all precautions that are necessary to operate in a correct way and in compliance with the laws in force about occupational safety.
- At the end of the operations, before re-starting the machine, check that no tool, cloth or other material has been left close to the moving devices or in hazardous areas.

HOW TO ADJUST TRANSMISSION CHAINS

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Open the cover **(A)**.
4. To evaluate if the chains are tightened in a correct way, the length of the spring **(D)** must equal 150 mm.
5. Adjust the length of the spring (and, as a consequence, the tensioning of the chain **(C)**) by means of the nuts **(B)** and the locknuts.
6. Close the cover **(A)**.




IDM-21722103100.pdf

HOW TO ADJUST CENTRALISED LUBRICATION

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Open the cover **(A)**.
4. Unscrew the plug **(B)**.
5. Adjust the quantity of oil.
 - TIGHTEN the screws **(C)** to increase the quantity.
 - LOOSEN the screws **(C)** to diminish the quantity.
6. Screw again the plug **(B)**.
7. Close the cover **(A)**.



IDM-46300101100.pdf

HOW TO ADJUST BELT ALIGNMENT

Follow the instructions.

Check that a finished bale is to be found inside the machine.

1. Make sure the tail gate is closed in a complete and correct way.
2. Make sure tractor PTO is disengaged.
3. Stop the engine, apply the parking brake and disengage the ignition key.
4. Check the direction (right or left) in which the belts have moved.


During bale creation, the belts could move laterally towards the corresponding divisions, and thus wear them out to an excessive extent.

Caution **Precaution**

During design and manufacturing, no measure was adopted to allow the operator to access the upper areas of the machine. If it becomes necessary to access the upper areas, prearrange suitable safety measures to prevent dangers, especially the danger of fall from height.


Belts that are moved to the right side.

1. On the right side of the machine, loosen the screws (A) and lower the roller (Q1) by using the adjustment screw (B).
As an alternative, you can perform a different operation.
On the left side of the machine, loosen the screws (A) and lift the roller (Q1) by using the adjustment screw (B).



Belts that are moved to the left side.

1. On the right side of the machine, loosen the screws (A) and lift the roller (Q1) by using the adjustment screw (B).
As an alternative, you can perform a different operation.
On the left side of the machine, loosen the screws (A) and lower the roller (Q1) by using the adjustment screw (B).
2. Start the engine of the tractor, activate the PTO and adjust it to its minimum rate.
3. Check the alignment between the belts and, if necessary, repeat the adjustment.




4. If it is necessary, correct the alignment only of side belts (D), "twist" the arms (C) of tighteners in one direction.



Important

Do not modify the position of the tightener springs. Only the manufacturer can perform the adjustment during machine manufacturing.



HOW TO ADJUST THE CLEANING ROLLERS

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.

Bladed roller to clean roller "M1"

3. Adjust the screws (B) to loosen the tightener (N).
4. On both sides, slightly loosen the nuts (C) that fasten the bearings.
5. Adjust the screw (A) and the locknut to position the blade-type roller (D).
Adjust the position of the blade-type roller (D) at a 3 mm distance from roller "M1" (E).

i Important

During the adjustment, the bladed roller must be kept in parallel position to roller "M1". To prevent damaging the roller "M1", do not position the blade-type roller at a distance that is smaller than the one specified in the picture.

6. Tighten the nuts (C) on both sides.
7. Adjust the screw (A) and the locknut to lock the blade-type roller (D).
8. Manually adjust tensioner (N) to regulate the tension of chain and, at the same time, tighten screws (B).

i Important

Do not tension the drive too much in order not to damage the rotating devices.


Bladed roller to clean roller "R4"

1. Open guards (M).
2. On both sides, slightly loosen the screws (F) that fasten the bearings.
3. Equally adjust the screw (G) and the locknut on both sides to set the position of the blade-type roller (H).


i Important

During the adjustment, the bladed roller must be kept in parallel position to roller "R4" (L). To prevent damaging the roller "R4", do not position the blade-type roller at a distance that is smaller than the one specified in the picture.

4. Tighten the screws (F-G) on both sides.
5. Close guards (M).



IDM-217221038610.pdf



IDM-217229031100.pdf

INSTRUCTIONS FOR MAINTENANCE

- Even though the machine was designed and manufactured to work in hard environmental conditions, you have to carry out scheduled maintenance interventions. Correct maintenance will allow achieving the best performance, a longer duration of work and a constant preservation of safety requirements.
- Before carrying out any maintenance operation, activate all safety devices and, if necessary, instruct the staff working on the machine or nearby. In detail, adequately mark the surrounding areas, and prevent the access to all devices that could cause unexpected hazardous conditions, as well as risks for the health and safety of people.
- Except what is expressly specified, every intervention has to be performed with disengaged PTO, and tractor engine off; furthermore, the ignition key must be removed and kept by the driver. The personnel that are authorised to perform the aforesaid interventions must comply with all precautions that are necessary to assure the safety of all people involved, and in compliance with the requirements of the laws in force about occupational safety.

PROGRAMMED MAINTENANCE INTERVALS CHART

Table 6: Intervals of periodic maintenance

<i>Frequency</i>	<i>Component</i>	<i>Type of intervention</i>	<i>Reference</i>
Each working day	Machine lubrication parts	Check that all greasing points of the machine are lubricated at specific intervals.	See "lubrication points diagram"
	Transmission unit	Check that the cardan shaft is correctly installed; furthermore, all protections must be undamaged and effective.	
		Lubricate the cardan shaft.	See "lubrication points diagram"
	Centralised lubrication system (optional)	Check the oil level in the tank and, if necessary, fill it up.	See "Oil supply for centralised lubrication"
		Check that all components are undamaged and, if necessary, replace them with original spare parts.	
	Hydraulic system	Check for possible oil leakages and tighten the couplings if necessary.	
Tyres	Check the wearing condition and the pressure of the tyres.		

Table 6: Intervals of periodic maintenance

Frequency	Component	Type of intervention	Reference
Each working day	Baling chamber	Check the wearing condition of the belts.	
		Check the alignment of the belts.	See "Check of belt alignment"
		Check the wearing condition of belt junctions and, if necessary, have them replaced.	Contact the Technical Assistance Centre that is authorised by the manufacturer
		Check that there is no product accumulation between the rollers and the belts; if necessary, remove the residues.	See "How to clean the belt guiding rollers"
	Signalling and lighting devices	Check the efficiency of the lamps and, if necessary, replace them.	
After 20 hours (since the first operation)	Transmission unit	Check the oil level in the reduction gear and, if necessary, fill it up.	See "Change of reduction gear oil"
Every 20 hours	Transmission unit	Check and, if necessary, adjust the chain tensioning.	See "How to adjust transmission chains"
	Closure devices for the lateral permanent guards	Check the efficiency and, if necessary, replace it	
	Twine or net introduction device	Clean and remove product residues. Carefully clean the driving chain and lubricate it.	See "lubrication points diagram"
Every 50 hours	Transmission unit	Check the wearing condition of pinions and chains.	
	Oil-pressure system	Check the efficiency of tail gate opening and closing operations.	
	Towing drawbar and eyelet	Make sure the fixing screws of the main parts are tightened properly.	
	wheel rims	Check the tightening of the fastening screws.	
Every year	Transmission unit	Change the oil of the reduction gear.	See "Change of reduction gear oil"
	Moving devices and machine structure	Check the wearing condition of bearings and, if necessary, replace them with original spare parts.	Contact the Technical Assistance Centre that is authorised by the manufacturer
		Make sure the fixing screws of the main parts are tightened properly.	
Net binder unit (electronic)			
After 10 hours (since the first operation)	Cutting device	Control and, if necessary, adjust the tightening of the device reset rope.	See "Net binder unit (electronic)" § "How to adjust the cut reset device"
Every 50 hours	Net drive rollers	Clean and remove possible net and/or product residues.	See "Net binder unit (electronic)" § "How to clean the net driving rollers"
Every 6 months	Net drive rollers	Check the efficiency of the rollers and, if necessary, replace damaged rollers	Contact the Technical Assistance Centre that is authorised by the manufacturer

Table 6: Intervals of periodic maintenance

Frequency	Component	Type of intervention	Reference
Every 12 months	Cutting device	Check the wearing condition and the cut efficiency of the blades and, if necessary, have the blades replaced.	Contact the Technical Assistance Centre that is authorised by the manufacturer
	Electro-clutch belt	Check the tightening and, if necessary, adjust it	See "Net binder unit (electronic)" § "How to replace the electro-clutch belt"
		Check the wearing condition and, if necessary, replace it	See "Net binder unit (electronic)" § "How to replace the electro-clutch belt"
	Rubber roller	Clean with compressed air and spread the rubber roller with talcum powder.	
Twine binder unit (electronic)			
Every 8 hours	Transmission unit	Clean with a water jet	
Every 100 hours	Transmission unit	Check and, if necessary, adjust the chain tensioning.	See "Twine binder unit (electronic)" § "How to adjust the chains of the twine guiding arms"
	Cutting arm	Check the wear and the efficiency of blade cut and, if necessary, replace the blade.	See "Twine binder unit (electronic)" § "How to replace the blade"
At season end	Transmission unit	Clean and lubricate	
Product feeding unit			
Every 8 hours	Feeding forks.	Check that there is no product accumulation between the feeding forks and the pick-up and, if necessary, remove the residues.	see "Product feeding unit" § "How to unflood the feeding unit"
Every 50 hours	Safety bolt	Check the efficiency and, if necessary, replace it	see "Product feeding unit" § "How to replace the safety bolt"
	Transmission	Check tightening of the transmission chain	
Every 6 months	Transmission	Clean and remove product residues.	
Pick-up unit			
Each working day	Reel	Check that the clamps are efficient and undamaged and, if necessary, have them replaced.	Contact the Technical Assistance Centre that is authorised by the manufacturer
		Check that the tines bars are efficient and undamaged and, if necessary, have them replaced.	Contact the Technical Assistance Centre that is authorised by the manufacturer
		Check that the tines are efficient and undamaged and, if necessary, have them replaced.	Contact the Technical Assistance Centre that is authorised by the manufacturer

Table 6: Intervals of periodic maintenance

<i>Frequency</i>	<i>Component</i>	<i>Type of intervention</i>	<i>Reference</i>
After 10 hours (since the first operation)	Auger transmission (left side)	Check and, if necessary, adjust the tensioning of the chain.	see "Pick-up unit § How to adjust the pick-up transmission chain"
Every 20 hours	Shock absorbers	Check pick-up unit balancing	see "Pick-up unit § How to balance the pick-up unit "
Every 50 hours	Safety bolt	Check the efficiency and, if necessary, replace it	see "Pick-up unit § "How to replace the safety bolt"
	Hydraulic system	Check that all pick-up unit driving components are undamaged and, if necessary, have them replaced.	Contact the Technical Assistance Centre that is authorised by the manufacturer
	Auger transmission (left side)	Check and, if necessary, adjust the tensioning of the chain.	see "Pick-up unit § How to adjust the pick-up transmission chain"
Every 100 hours	Reel	Check the efficiency of the bearings and, if necessary, have them replaced.	Contact the Technical Assistance Centre that is authorised by the manufacturer
Every 12 months	Reel	Check the efficiency of the cams and, if necessary, have them replaced.	Contact the Technical Assistance Centre that is authorised by the manufacturer

LUBRICANT TABLE

Use oils and lubricants whose features are the same as the ones that are specified in the chart.

Table 7: Features of the lubricants

<i>Suggested lubricants</i>	<i>Parts to lubricate</i>	<i>Quantity</i>
oil AGIP F1 - EP 90 (SAE 80W90)	Reduction gear	2,3 l
oil AGIP F1 - ROTRA THT	Hydraulic cylinder of the tightener unit	5 l
oil SAE 20W - ISO VG 46 - ISO VG 68	Automatic lubrication system	2 l
grease AGIP LF1	Greasers	-
	Driving rollers	-

DRIVING TORQUE TABLE

Check all the elements of the fastening of the various components of the machine with a dynamometric key. Respect the driving torque indicated in the table.



Danger Warning

Substitute the fastening elements that have deteriorated.

Table 8: Tightening torque for standard screws

Screw sizes	Driving torque (Nm)					
	Resistance class 8.8		Resistance class 10.9		Resistance class 12.9	
	Nm	ft-lb	Nm	ft-lb	Nm	ft-lb
M3	1,3	0,9	1,8	1,3	2,1	1,5
M4	2,9	2,1	4,1	3,0	4,9	3,6
M5	5,7	4,2	8,1	6,0	9,7	7,1
M6	9,9	7,3	14,0	10,3	17,0	12,5
M8	24,0	17,7	34,0	25,0	41,0	30,3
M10	48,0	35,4	68,0	50,2	81,0	59,8
M12	85,0	62,7	120,0	88,6	145,0	107,0
M14	135,0	99,6	190,0	140,0	225,0	166,0
M16	210,0	155,0	290,0	214,0	350,0	258,0
M18	290,0	214,0	400,0	295,0	480,0	354,0
M20	400,0	295,0	570,0	421,0	680,0	502,0
M22	550,0	406,0	770,0	568,0	920,0	679,0



Important

Such values have been obtained experimentally and for serial applications, one is advised to check them with field tests.

LUBRICATION POINTS DIAGRAM



Caution Precaution


**Make sure tractor PTO is disengaged.
Stop the engine, apply the parking brake and disengage the ignition key.**

Lubricate the devices in the points and at the specified intervals.



Important



Before lubricating, thoroughly clean the implied devices and the greasers to prevent impurities from being mixed with the lubricant.



IDM 483-004-0.fm

IDM-4830040000.pdf


Legend



CHECK OF BELT ALIGNMENT

Follow the instructions.


1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Check that a finished bale is to be found inside the machine.
4. Unscrew the screws to disassemble the guard (A).
5. Check if the wearing condition of the divisions (B) is uniform on both sides. If the divisions are worn more on one compared to the other side, you have to align the belts (See "How to adjust belt alignment").
6. Assemble the guard (A), and then fasten it by using the screws.



CHANGE OF REDUCTION GEAR OIL

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Prepare a container with suitable capacity.
4. Unscrew the filling cap (A).
5. Unscrew the drain plug (B) and drain the oil in the container completely.
6. Screw the drain plug (B) back on.
7. Unscrew the plug (C).
8. Pour the new oil through the filling plug (A).
9. Stop pouring the oil before it starts leaking from the plug hole (C).
10. Screw again the plug (C).
11. Retighten the filler plug (A) and check for leaks.



Caution

Use oils whose features are similar to the ones that are specified in the "Lubricant table".

Important

Do not throw away any polluting material in the environment. Carry out their disposal in compliance with the relevant legislation in force.


OIL SUPPLY FOR CENTRALISED LUBRICATION

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Open the cover (A).
4. Thoroughly clean the area so that no dust or residues can enter the tank.
5. Unscrew the filling cap (B).
6. Check the conditions of the filter (C) and carefully clean it in case of clogging.
7. Pour new oil into the tank.
8. Tighten the filling cap (B).
9. Close the cover (A).

Caution

Use oils whose features are similar to the ones that are specified in the "Lubricant table".




HOW TO CLEAN THE BELT GUIDING ROLLERS

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the machine; the engine of the tractor must be on and the parking brake must be applied.
3. Open the cover (A).
4. Place the lever of the hydraulic control valve in the tractor in position 1 to fully open the tail gate.
5. Remove the safety pin (B) from the hole (C1) of the pin (C), push the pin inside and introduce the safety pin (B) into hole (C2).

Important

In order to prevent pin (C) from breaking, it can be introduced only after the tail gate is completely open.




Caution
Precaution

Make sure that the hitch pin (C) is fully introduced to assure that the tightener unit rests on the hitch pin.

If it is not possible to completely introduce the pin (C), contact the Manufacturer's or the local dealer's After-Sales Service.

- Adjust the lever of the tractor hydraulic control valve in position 2, and then release it when the tightener unit (D) leans on the component (C). This way, the belts will loosen.




- Close the cock (E) to assure safety conditions.
- Switch off the engine of the tractor, and then disengage the ignition key.
- Clean and remove product residues between the rollers and the belts.
- Check the general conditions of the devices in the baling chamber.
- Open the cock (E).

Caution
Precaution

Before opening the cock, make sure that the cleaning operations have been completed.

- Start the engine of the tractor from the driver's seat.
- Place lever of the hydraulic control valve in the tractor in position 1 to open the tail gate.
- Remove the locking pin (B) and the hitch pin (C); after that, re-introduce the plug into the hole (C1).
- Place the lever of the hydraulic control valve in the tractor in position 2 to close the tail gate.
- Close the cover (A).



HOW TO STORE THE MACHINE AT SEASON END

Before storing the machine, it is necessary to perform some general maintenance operations, which will help in ensuring its perfect operation as soon as the new harvesting campaign starts.

Follow the instructions.


- Uncouple the machine from the tractor (See "How to uncouple the machine from the tractor").
- Disconnect the electronic control system, and then store it in a dry and sheltered place.
- Remove product and dust residues from all parts of the machine, especially from the baling chamber.



Important

Prevent spraying pressure water jets against the bearing seals.

- Check the efficiency of all machine devices and, if necessary, replace them with original spare parts.
- Check that the cardan shaft is correctly engaged to the machine and that it rests on the specific support; all protections must be undamaged and efficient.
- In the models with double feeder, remove the lateral closures of the platform and clean the product feeding unit internal drive (see picture).
- Thoroughly clean the transmission chains, and then abundantly lubricate them.
- Grease the components provided with greaser.
- Lubricate all sliding surfaces, especially the rods of oil-pressure cylinders.
- Apply an anti-rust treatment on all non-painted parts.
- Keep the belts of the baling chamber tightened in order to reduce the risk of deformations and to extend their duration.
- Spread the driving rollers of the net binder unit with a specific product (for example, talc) to prevent the deterioration of rubber surfaces.
- Protect the connectors of the electric wiring by using the specific plugs.
- Protect the quick couplings of the oil-pressure hoses by using the specific plugs.
- Store the machine in a sheltered place (preferably in indoor premises) that can be accessed only by authorised personnel.



PUTTING THE MACHINE INTO SERVICE

Before using the machine after a long period of inactivity, carefully check that the main components are working correctly.

In particular:

- Check the wearing condition and the pressure of the tyres.
- Check possible loss of liquids.
- Check the general conditions of the hydraulic hoses.
- Check the efficiency of all safety devices.
- Check the oil level in the centralised lubrication system and, if necessary, fill it up.
- Lubricate all greasing points.
- Carry out all the necessary maintenance operations.
- Check that the cardan shaft is correctly installed; furthermore, all protections must be undamaged and effective.
- Check the tightening of the fastening screws for the main devices (drawbar, towing eye, and wheel fastening nuts).
- Couple the machine to the tractor (See "How to couple the machine to the tractor").
- Simulate some test manoeuvres to check coupling, correct operation of the controls and functionality of operator units.

SPECIAL MAINTENANCE

- Although the machine was designed and built to work in difficult environmental conditions, after a few years special maintenance must be carried out to preserve perfect efficiency and guarantee general safety.
- The aforesaid interventions must be carried out by personnel with precise technical skills, in workshops that are suitably equipped and authorised by the manufacturer.
- The flexible hoses in the hydraulic system must be replaced every 6 years from the date of production. These components are subjected to stress due to ageing.

INSTRUCTIONS FOR PART REPLACEMENT



Except in case it is expressly specified, every intervention must be performed with disengaged PTO and tractor engine off; furthermore, the ignition key must be removed and kept by the driver. The personnel that are authorised to perform the interventions must comply with all precautions that are necessary to assure the safety of the people involved, in compliance with the requirements established by the laws in force about occupational safety.

Before carrying out any replacement operation, activate all safety devices and, if necessary, instruct the staff working on the machine or nearby.

If it is necessary to replace worn components, only use original spare parts. The manufacturer disclaims all responsibility for damages to people or components, which are caused by the use of non-original spare parts and special interventions that can modify the safety requirements without being authorised by the manufacturer. To order the spare parts, follow the instructions that are specified in the spare parts catalogue.

HOW TO REPLACE THE TYRES

Follow the instructions.

1. Position the machine on a compact and level ground to assure the stability of the lifting devices.
2. Stop the machine in safe conditions.
3. Stop the engine, apply the parking brake and disengage the ignition key.




Caution Precaution

The tyre replacement operation can cause risks, also considering the total weight of the machine.

To prevent risks (even serious), it is advisable to make the operation be performed by expert personnel (for example, a tyre man), who are capable of performing the intervention a correct and safe way.

If it is not possible to make the operation be performed by expert personnel, it is crucial to implement all safety conditions that are necessary to prevent sudden and uncontrolled displacements of the machine or parts of it.

4. Place two safety chocks (A) opposite to the tyre to be replaced, as shown in the figure.
5. Slightly loosen the nuts (B).
6. Introduce the lifting device (C) into the point that is specified by the proper plate, which is installed close to the tyre to be replaced.
7. Lift the machine to allow wheel disassembly.
8. Fully unscrew the nuts (B), and then assemble the wheel.
9. Replace the tyre.
10. Assemble the wheel once more, and then screw the nuts in a symmetrical way.
Tighten the nuts with a tightening torque equalling 310 Nm.
11. Lower the machine, and then tighten the nuts (B).
12. Inflate the tyre until reaching the pressure that is specified in the chart (See "Technical Data").
13. Remove the lifting device (C) when the operation is complete.
14. Remove the safety wedges (A).
15. Check nut tightening after 2-3 working hours.




IDM-21722104500.pdf

HOW TO REPLACE THE BELTS OF THE BALING CHAMBER

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the machine; the engine of the tractor must be on and the parking brake must be applied.
3. Place the lever of the hydraulic control valve in the tractor in position **1** to fully open the tail gate.
4. Close the cock **(A)** to assure safety conditions.
5. Loosen belts (See "How to clean the belt guiding rollers").
6. Switch off the engine of the tractor, and then disengage the ignition key.




7. Remove the pivot from the connection of the belt **(B)**.
8. Remove the belt **(B)**.

If more belts are removed, mark some references so that you will be able to reinstall the belts in the original position.

9. Assemble a new or repaired belt **(B)**. Install the belt on the guide pulleys and pay attention to the direction of the belt bevel relating to the forward direction of the same belt (see the figure).

During the re-assembly of the belt, pay attention that the copper plated iron round-bar is on the side of the belt on contact with the bale.



Important

If it is necessary to restore the junction, trim the edges of the belt with a cutter in the ends without bevels to prevent an unwanted enlargement due to the assembly of the same junction.


It is advisable to assemble the new belts in central position.

The difference in length of the belts that are installed on the machine has never to exceed 30 mm.

10. On the bevelled part of the belt, cut the external hook closest to the edge of the belt.

This way, the side hooks on the bevelled part of the belt keep inside the hooks on the non-bevelled part.


11. Assemble the pivot with welded hook , as shown in the picture.
12. Start the engine of the tractor from the driver's seat.
13. Open the cock **(A)**.
14. Place the lever of the hydraulic control valve in the tractor in position **2** to close the tail gate.




MANUAL EQUIPMENT FOR VICE ("MATO" TYPE JUNCTIONS)

Follow the instructions.


1. Square the end of the belt.



2. Position and tighten the equipment "Profi 19", which is completely open, in a bench vice with the holes pointing forward.




3. Introduce the junctions into the holes of the equipment.
Start the operation from the left holes.




4. Introduce two pivots at a time into a single hole.




5. Before introducing the belt, tighten the vice until the junctions are slightly tightened and the belt can be easily introduced.




6. Introduce the first end of the belt. Position the edge of the belt close to the mark (width of the belt or number of the couplings).




7. Press the belt downwards in a uniform way up to the stop pins, and then tighten the vice until the junctions are slightly tightened.




8. The belt must lean on the stop pins. Close the junction until it touches the surface of the belt.




9. By using a hammer, introduce the punch into the left hole until its side touches the equipment. Hit the punch other 3 times to create the head of the nail.




10. By using a hammer, introduce all nails into the belt (proceed from the right to the left).



This procedure can be simplified if you use a hammer drill with a special body.




11. Open the vice and slightly press the belt backwards to remove it.




12. Crush the nails on a solid base.


Pay attention not to hit or damage the circular part of the coupling.




13. In case of belts having a different width, twist and remove the exceeding hooks.



14. Cut off the protruding weld bead.




The same connection method can be applied to belts of any width.




15. Repeat the whole procedure for the other end of the belt.


 Important
The same side of the belt must be turned forward.




16. Bevel the corners of a single end of the belt. Leave 1 mm of belt adjacent to the coupling, and then cut ~25 mm.




17. To join the ends of the belt, connect the junctions together and make sure that the ends of the belt are aligned; after that, introduce the junction pivot.



The bevelled end must move forward in the driving direction.



18. For a perfect assembly, remove the rubber particles that have been trapped by the tool using a small metal brush.



MACHINE DISPOSAL

In phase of abandonment, it is necessary to carry out a series of interventions so that the machine and all of its devices do not constitute an obstacle and so that they are not easily accessible.

To avoid that the machine might constitute dangers for persons and the environment, it is necessary to disconnect and render all the feeds unusable (electric, pneumatic, hydraulic, etc.) and to remove any possible liquids (lubrication, oils, etc.) that might be present.

Deposit the machine in a suitable zone, not easily accessible and opportunely bounded so as to prevent anyone having access to it.

MACHINE DEMOLITION

Whoever is authorised to carry out the demolition of the machine has to, if necessary, enable a "safety plan" to safeguard the safety of the persons directly involved and to rigorously apply all the norms in force on safety in the workplace and mobile work yards.

During the demolition phase, divide all the components according to their chemical characteristics and carry out the separated waste treatment according to relevant norms in force.



Important

Do not dispose of non-biodegradable products, lubricating oils and non-ferrous materials (rubber, PVC, resins, etc.). The materials must be disposed in accordance with the current regulations in force.

TROUBLES, CAUSES, REMEDIES

The purpose of the following information is to identify and correct possible faults and malfunctions that may occur when using the machine.

The various irregularities that may occur were divided into tables, according to the reference operator unit. It is advisable to examine all tables to know the possible irregularities in a more thorough way.

In case of irregularities that are not specified in the table, the operator can signal them to the manufacturer in order to actively contribute in developing new solutions, as well as construction and technical improvements.

Some faults can be solved by the operator; others need a specific technical competence or particular skills, and must be carried out only by qualified personnel with well-known experience and acquired within the specific sector of intervention.

In case of need, call the After-Sales Service of the manufacturer, of the local dealer or an authorised workshop.

Table 1: Product defects

<i>Trouble</i>	<i>Cause</i>	<i>Cure</i>	<i>Reference</i>
Light bale.	The windrow was not prepared correctly.	Correct the preparation of the windrow.	see "How to prepare the product windrow" in booklet 2
	The speed of the forward movement is too high	Decrease the speed of the forward movement.	
	The PTO rotation rate is too low.	Increase the PTO rate.	
	The path of the forward movement is not correct.	Modify the path of the tractor.	see "Instructions about product pick-up" in booklet 2
	The density pressure of the bale is insufficient.	Increase the set pressure.	see "How to adjust the solenoid valve for bale density " in booklet 2
	Presence of air inside the hydraulic circuit for bale density.	Bleed the air from the circuit.	
Too heavy bale.	The windrow was not prepared correctly.	Correct the preparation of the windrow.	see "How to prepare the product windrow" in booklet 2
	The forward movement speed is too low.	Increase the speed of the forward movement.	
	Bale density pressure is too high.	Reduce the set pressure.	see "How to adjust the solenoid valve for bale density " in booklet 2
	Product whose humidity percentage is too high.	Reduce the humidity percentage.	
Conical bale.	The forward movement path is not correct: excessive feeding on one side.	Modify the path of the tractor.	see "Instructions about product pick-up" in booklet 2

Table 1: Product defects

<i>Trouble</i>	<i>Cause</i>	<i>Cure</i>	<i>Reference</i>
Barrel-shaped bale.	The forward movement path is not correct: excessive feeding at the centre.	Modify the path of the tractor.	see "Instructions about product pick-up" in booklet 2
Surface of the bale with rolled and chopped product.	The product is too dry.	Pick up the product when cooler.	
	Bale density pressure is too high.	Reduce the set pressure.	see "How to adjust the solenoid valve for bale density " in booklet 2
	The PTO rotation rate is too high.	Reduce the PTO rate.	
The bale compressed with twine binding breaks down.	The product is too dry.	Pick up the product when cooler. Perform the binding operation with the net binder (if installed).	
	Bale density pressure is too high.	Reduce the set pressure.	see "How to adjust the solenoid valve for bale density " in booklet 2
	The PTO rotation rate is too high.	Reduce the PTO rate.	

Table 2: Operation irregularities of the machine

<i>Trouble</i>	<i>Cause</i>	<i>Cure</i>	<i>Reference</i>
The machine gets clogged with the product	Too big or irregular bale.	Correct the windrow dimension	see "How to prepare the product windrow" in booklet 2
	The speed of the forward movement is too high	Decrease the speed of the forward movement.	
	The path of the forward movement is not correct.	Modify the path of the tractor.	see "Instructions about product pick-up" in booklet 2
	The PTO rotation rate is too low.	Increase the PTO rate.	
	The baffle plate is not adjusted in a correct way.	Lower the position of the baffle plate.	see "How to adjust the baffle plate" in booklet 4
The tail gate does not close correctly.	Product debris between the fixed part of the machine and the tail gate.	Remove product debris from the baling chamber.	see "How to clean belt guide rollers" in booklet 2
	The side hooks are not coupled to gate side rollers.	After hatch closing wait for the hooks to close before releasing the hydraulic control. Avoid counter-pressures on the hydraulic circuit that could operate the hydraulic cylinders.	

Table 2: Operation irregularities of the machine

<i>Trouble</i>	<i>Cause</i>	<i>Cure</i>	<i>Reference</i>
As soon as the pressurization and closing operations have ended, the hooks of the tail gate accidentally disconnect.	There is a residual pressure within the oil return hydraulic circuit to the tank.	Connect the return hose to an element of the tractor hydraulic control valve (floating position).	see "How to couple the machine to the tractor" in part 2
Excessive noise of the transmission.	The chains are not adjusted correctly	Adjust chain tension	see "How to adjust the transmission chains" in booklet 2
During the unloading operation, with the machine being equipped with kicker, the bale keeps inside the baling chamber.	The roller of the bale kicker is not positioned in a correct way.	Position the roller in the first hole of the bale kicker.	
The augers do not operate correctly.	Too narrow windrow.	Modify the path of the tractor with movements to the left and to the right.	see "Instructions about product pick-up" in booklet 2
The belts do not work correctly and their duration is limited.	The path of the forward movement is not correct.	Modify the path of the tractor.	see "Instructions about product pick-up" in booklet 2
	the guide rollers are not positioned in a correct way	adjust the position of the rollers	see "How to adjust belt alignment" in booklet 2
	Product accumulation and/or twine in the rollers.	Remove the accumulation of material.	see "How to clean belt guide rollers" in booklet 2
	The windrow was not prepared correctly.	Correct the preparation of the windrow.	see "How to prepare the product windrow" in booklet 2
	Product whose humidity percentage is too high.	Reduce the humidity percentage.	
	Irregular and excessive extension of some belts.	Level the length of the belts.	Operations to be performed by specialised personnel at authorised workshops

Table 3: Operation irregularities of the pick-up unit

<i>Trouble</i>	<i>Cause</i>	<i>Cure</i>	<i>Reference</i>
Irregular product pick-up	Too high pick-up.	adjust the position of the wheels in the pick-up unit.	see "How to adjust the height of the pick-up unit" in booklet 4
	Balancing is not correct.	Adjust the suspension spring.	see "How to balance the pick-up unit" in booklet 4
	The baffle plate is not adjusted in a correct way.	Adjust the position of the baffle plate.	see "How to adjust the baffle plate" in booklet 4

Table 4: Operation irregularities of the net binder unit

<i>Trouble</i>	<i>Cause</i>	<i>Cure</i>	<i>Reference</i>
The net driving rollers in the net binder unit do not rotate.	Product accumulation between the driving rollers.	Clean the surface of the net driving rollers and remove product debris, if any.	see "How to clean the net driving rollers" in booklet 6
	The contact pressure between the net driving rollers is too high.	Adjust the contact pressure of the net driving rollers.	see "How to adjust the pressure of the net driving rollers" in booklet 6
The net driving rollers in the net binder unit rotate, but the net reel is not drawn.	Net meshes are too wide.	Use a suitable net reel.	see "Technical data" in booklet 2
	The contact pressure between the net driving rollers is insufficient.	Adjust the contact pressure of the net driving rollers.	see "How to adjust the pressure of the net driving rollers" in booklet 6
The net gets too much narrow during ball winding.	The net reel is not assembled correctly.	Assemble the net reel according to the correct path.	see "How to supply the net reel" in booklet 6
	The reel brake is not adjusted in a correct way.	Adjust the reel brake.	see "How to adjust the reel brake" in booklet 6
	Net meshes are too wide.	Use a suitable net reel.	see "Technical data" in booklet 2
	The contact pressure between the net driving rollers is too high.	Reduce the contact pressure between the net driving rollers at the side ends, and then increase it at the centre, if necessary.	see "How to adjust the pressure of the net driving rollers" in booklet 6
The cutting device is not reset when the tail gate opens.	The reset device is not adjusted in a correct way.	Adjust the reset device.	see "How to adjust the reset device" in booklet 6

Table 5: Operation irregularities of the twine binder unit

<i>Trouble</i>	<i>Cause</i>	<i>Cure</i>	<i>Reference</i>
During twine binding, the twine comes out on the side of the bale.	A barrel-shaped bale is caused by an incorrect forward movement path, with excessive feeding at the centre.	Modify the path of the tractor.	see "Instructions about product pick-up" in booklet 2
	The product is too dry.	Pick up the product when cooler.	
	Bale density pressure is too high.	Reduce the set pressure.	see "How to adjust the solenoid valve for bale density" in booklet 2
	The twine is not tightened in a sufficient way.	Adjust the twine tightening clamps.	see "How to adjust the twine tightening clamps" in booklet 7

Table 5: Operation irregularities of the twine binder unit

Trouble	Cause	Cure	Reference
The twine guiding arms are not positioned correctly.	The transmission chain is dirty.	Clean using compressed air and re-position the right twine guiding arm.	See "How to adjust the twine guiding arm chains" in part 7
	The transmission chain is worn.	Get the chain repaired or replaced by the nearest authorized Technical Assistance Centre.	
	Faulty potentiometer	Get the potentiometer repaired or replaced by the nearest authorized Technical Assistance Centre.	
The twine guiding arms do not move.	Blown fuse	Replace the fuse	
	Damaged electric motor	Get the motor repaired or replaced by the nearest authorized Assistance centre.	
One or both twines are not drawn by the bale at the start of the binding operation.	The twine is not assembled correctly	Assemble the twine according to the correct path.	see "How to introduce the twine" in booklet 7
	Twine braking is excessive.	Adjust the twine tightening clamps.	see "How to adjust the twine tightening clamps" in booklet 7
	The twine does not sufficiently go out of the twine guiding arm	Make the twine go out of the twine guiding arm of about 25÷30 cm.	see "How to introduce the twine" in booklet 7
	The binding element introduction unit does not operate	Check and contact a Technical Assistance Centre that is authorised by the Manufacturer	
	The machine has run out of twine reels	Supply twine reels into the twine case.	see "How to supply the twine reels" in booklet 7
Twine binding is not performed.	The machine has run out of twine reels	Supply twine reels into the twine case.	see "How to supply the twine reels" in booklet 7
	The knot that joints the twine reels was not performed correctly.	Check the joint knots and, if necessary, knot them again.	see "How to supply the twine reels" in booklet 7
	The cutting arm was not adjusted correctly	Check and contact a Technical Assistance Centre that is authorised by the Manufacturer	
The twine is not cut correctly	Cutting blades are worn.	Sharpen the blades or replace them  Important Wear protective gloves for this operation.	see "How to replace the blades" in booklet 7
	The cutting arm was not adjusted correctly	Check and contact a Technical Assistance Centre that is authorised by the Manufacturer	

Table 5: Operation irregularities of the twine binder unit

<i>Trouble</i>	<i>Cause</i>	<i>Cure</i>	<i>Reference</i>
The twine is not cut correctly	Product accumulation in the cutting arm.	Remove the accumulation of material.	
	The springs that operate over the clamps during the final phase of the binding process do not press sufficiently.	Replace the springs	
The twine guiding arms get stuck.	Faulty potentiometer	Get the potentiometer repaired or replaced by the nearest authorized Technical Assistance Centre.	
	The PTO rotation rate is too low.	Increase the PTO rate.	

GENERAL DESCRIPTION


The pick-up unit picks the product in the windrow and conveys it into the machine feeding area.

The functions of the unit are activated by the main motor drive of the machine where it is installed.

The pick-up unit is equipped with a safety bolt , which, in case of product clogging, gets sheared to prevent damages to units or parts of the machine.


If it is necessary to replace the safety bolt, use an original spare part.

- **"Reel" device (A)**: it makes the product pick-up operation easier, and is equipped with two cams that guide the tine-holder rods.
- **Baffle plate (B)**: it allows a more regular feeding of the product, even in case of short and chopped products.
The baffle plate can be fixed or tilting.
- In the machines equipped with balancing baffle plate and rotor or cutting device roller **(B1)** is also installed, which further improves the feeding of the product.
- **Auger (C)**: there are two augers (one on each side), which convey and adapt the product to the width of the baling chamber.
- **Wheel (D)**: there are two wheels (one on each side) and, thanks to a shock absorber system **(E)**, they allow the pick-up unit to adapt itself to the different conformations of the ground.



OIL-PRESSURE DEVICES

- **Hydraulic cylinder (A):** it lifts and lowers the pick-up unit.




IDM-217206002001.pdf

HOW TO HANDLE THE PICK-UP UNIT

1. During the normal working conditions, keep the cock (C) open in order to be able to lift and lower the pick-up unit.
2. Place the lever (B) of the hydraulic control valve in the tractor in position 1 to lift the pick-up unit (A), or rather in position 2 to lower it.

⚠ Important
In case the machine must be transferred, close the cock (C) to keep the pick-up unit lifted in safe conditions.
Fasten the pick-up unit by using the specific chain.




IDM-24830070200.pdf

HOW TO REMOVE PRODUCT CLOGGING IN THE PICK-UP UNIT

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Remove the product that clogs the pick-up unit (A) by using the specific tool (B).
4. Disassemble the baffle plate, if necessary, to make the product removal easier.
5. Restart the motor, and then activate the power take-off to check if the pick-up unit has unlocked.
If not so, open the tail gate and activate the bale unloading to make the product removal operation easier.



HOW TO BALANCE THE PICK-UP UNIT

Balancing has to be performed according to the speed of the forward movement of the machine, as well as to the conformation of the ground. A correct balancing allows the pick-up unit to keep resting on the ground with the wheels, and to lift correctly when it knocks against an obstacle.


i Important

The pick-up unit must be balanced in such a way as to exercise a force of approximately 300÷400 N (30÷40 kg) over the soil.

To perform balancing, follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Open the cover (A).
4. Adjust the compression of the spring (D) by means of the lock nut (B) and the tightener (C).
 - Screw the tightener (C) to reduce spring (D) loading.
 - Loosen the tightener (C) to increase spring (D) loading.
5. Tighten the lock nut (B) when the operation is completed.
6. Close the cover (A).

The dimension shown in the picture is approximate. Its value may vary according to the position and the work conditions of the pick-up unit.




HOW TO ADJUST THE HEIGHT OF THE PICK-UP UNIT

The height of the pick-up unit must be adjusted according to the product to be picked up and to the conformation of the windrow.

During the pick-up operations, the tines of the pick-up unit have not to knock against the ground.

To perform the adjustment, follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Lift the pick-up unit in such a way as to detach the wheels from the ground.
3. Stop the engine, apply the parking brake and disengage the ignition key.
4. Fasten the pick-up unit by using the specific chain.
5. Remove the safety pin (A).
6. Disconnect the safety plate (B).
7. Slightly extract the wheel-holder arm (C), and then rotate it to obtain the desired height.
8. Re-introduce the arm into the new hole.
9. Reintroduce the safety plate (B).
10. Place the safety pin (A).
11. Repeat the same operation on the other side and make sure to use the same hole.



IDM-4830070400.pdf


HOW TO ADJUST THE FIXED BAFFLE PLATE

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Unscrew the nuts (A).
4. Modify the position of the hitch pins (B) to adjust the baffle plate in the desired position.

⚠ Important
For optimal adjustment, insert the pins into the holes.

5. Re-screw the nuts (A).
6. Repeat the same operation on the other side and make sure to use the same holes.



IDM-48300701100.pdf


HOW TO ADJUST THE TILTING BAFFLE PLATE

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.


How to adjust the height of the baffle plate

3. Remove the safety pin (A).
4. Release the chain (B), and then reconnect it in such a way as to position the baffle plate at the desired height.
5. Place the safety pin (A).
6. Repeat the same operation on the other side and make sure to use the same holes.




How to adjust the baffle plate inclination

7. Loosen the nuts (C-D) on both sides.
8. Set the inclination of the baffle plate (E) and lightly tighten the nuts (C).
9. Tighten nuts (C-D).



How to adjust the feed roller position

10. Loosen the nuts (C-D) on both sides.
11. Adjust the position of the roller (F), and then slightly tighten the nuts (D).
12. Tighten nuts (C-D).




IDM-4630070070.pdf

HOW TO ADJUST THE PICK-UP TRANSMISSION CHAIN

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Unscrew the screws to disassemble the guard (A).
4. Loosen the nut (B), displace the tightener (C) to adjust the tension of the chain, and then tighten the nut (B).
5. Assemble the guard (A), and then fasten it by using the screws.



IDM-463007008000.pdf


 Important

Control the chain every 50 working hours and, if necessary, perform the adjustment to prevent it from coming out of the pinion.


HOW TO REPLACE THE SAFETY BOLT

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Remove the product that clogs the pick-up unit by using the specific tool (See "How to remove product clogging in the pick-up unit").
4. Unscrew the screws to disassemble the guard **(A)**.



5. Remove the damaged parts of the safety bolts **(F)**.
6. Introduce the tool **(B)** into the hole **(C)**.
7. By using the tool, lever it to align the hole of the flange **(D)** to the holes of the pinion **(E)**.
8. Assemble the new safety bolt **(F)**.
9. Assemble the guard **(A)**, and then fasten it by using the screws.



**Page intentionally left
without information**

GENERAL DESCRIPTION


The pick-up unit picks the product in the windrow and conveys it into the machine feeding area.

The functions of the unit parts are activated by the main motor drive of the machine where it is installed.

Unit is equipped with clutch that, in case of clogging, automatically releases itself to avoid damaging the machine.


After having restored normal working conditions of the unit, the clutch automatically re-inserts itself.

- **"Reel" device (A)**: it makes the product pick-up operation easier, and is equipped with two cams that guide the tine-holder rods.
- **Baffle plate (B)**: it allows a more regular feeding of the product, even in case of short and chopped products.
In the machines equipped with a rotor or cutting device , roller **(B1)** is also installed, which further improves the feeding of the product.
- **Auger (C)**: there are two augers (one on each side), which convey and adapt the product to the width of the baling chamber.
- **Wheel (D)**: there are two wheels (one on each side) and, thanks to a shock absorber system **(E)**, they allow the pick-up unit to adapt itself to the different conformations of the ground.



OIL-PRESSURE DEVICES

- **Hydraulic cylinder (A):** it lifts and lowers the pick-up unit.




IDM-217206002001.pdf

HOW TO HANDLE THE PICK-UP UNIT

1. During the normal working conditions, keep the cock (C) open in order to be able to lift and lower the pick-up unit.
2. Place the lever (B) of the hydraulic control valve in the tractor in position 1 to lift the pick-up unit (A), or rather in position 2 to lower it.

i Important

In case the machine must be transferred, close the cock (C) to keep the pick-up unit lifted in safe conditions. Fasten the pick-up unit by using the specific chain.




IDM-248300700200.pdf

HOW TO REMOVE PRODUCT CLOGGING IN THE PICK-UP UNIT

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Remove the product that clogs the pick-up unit (A) by using the specific tool (B).
4. Disassemble the baffle plate, if necessary, to make the product removal easier.
5. Restart the motor, and then activate the power take-off to check if the pick-up unit has unlocked.
If not so, open the tail gate and activate the bale unloading to make the product removal operation easier.



HOW TO BALANCE THE PICK-UP UNIT

Balancing has to be performed according to the speed of the forward movement of the machine, as well as to the conformation of the ground. A correct balancing allows the pick-up unit to keep resting on the ground with the wheels, and to lift correctly when it knocks against an obstacle.


i Important

The pick-up unit must be balanced in such a way as to exercise a force of approximately 300÷400 N (30÷40 kg) over the soil.

To perform balancing, follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Open the cover (A).
4. Adjust the compression of the spring (D) by means of the lock nut (B) and the tightener (C).
 - Screw the tightener (C) to reduce spring (D) loading.
 - Loosen the tightener (C) to increase spring (D) loading.
5. Tighten the lock nut (B) when the operation is completed.
6. Close the cover (A).

The dimension shown in the picture is approximate. Its value may vary according to the position and the work conditions of the pick-up unit.




HOW TO ADJUST THE HEIGHT OF THE PICK-UP UNIT

The height of the pick-up unit must be adjusted according to the product to be picked up and to the conformation of the windrow.

During the pick-up operations, the tines of the pick-up unit have not to knock against the ground.

To perform the adjustment, follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Lift the pick-up unit in such a way as to detach the wheels from the ground.
3. Stop the engine, apply the parking brake and disengage the ignition key.
4. Fasten the pick-up unit by using the specific chain.
5. Remove the safety pin (A).
6. Disconnect the safety plate (B).
7. Slightly extract the wheel-holder arm (C), and then rotate it to obtain the desired height.
8. Re-introduce the arm into the new hole.
9. Reintroduce the safety plate (B).
10. Place the safety pin (A).
11. Repeat the same operation on the other side and make sure to use the same hole.



IDM-48300700400.pdf


HOW TO ADJUST THE TILTING BAFFLE PLATE

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.

How to adjust the height of the baffle plate


3. Remove the safety pin (A).
4. Release the chain (B), and then reconnect it in such a way as to position the baffle plate at the desired height.
5. Place the safety pin (A).
6. Repeat the same operation on the other side and make sure to use the same holes.



IDM-48300700500.pdf


How to adjust the baffle plate inclination

7. Loosen the nuts (C-D) on both sides.
8. Set the inclination of the baffle plate (E) and lightly tighten the nuts (C).
9. Tighten nuts (C-D).



How to adjust the feed roller position


10. Loosen the nuts (C-D) on both sides.
11. Adjust the position of the roller (F), and then slightly tighten the nuts (D).
12. Tighten nuts (C-D).



HOW TO ADJUST THE PICK-UP TRANSMISSION CHAIN

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Unscrew the screws to disassemble the guard (A).
4. Loosen the nut (B), displace the tightener (C) to adjust the tension of the chain, and then tighten the nut (B).
5. Assemble the guard (A), and then fasten it by using the screws.




Important
Control the chain every 50 working hours and, if necessary, perform the adjustment to prevent it from coming out of the pinion.

**Page intentionally left
without information**

GENERAL DESCRIPTION


The "ROTOR" feeding unit transfers the product to the baling chamber. The functions of the unit parts are activated by the main motor drive of the machine where it is installed.

- **Feeder device (A)**: it receives the product from the pick-up unit and transfers it to the baling chamber.
- **Scraper (B)**: prevents the backflow and the product from wrapping around feeding device.
- **"Drop floor" device (C)**: used to unblock the feeding unit in case of clogging.




ELECTRICAL DEVICES

- **Sensor (A)**: indicates the deck of the "Drop floor" device in the "raised" position.



OIL-PRESSURE DEVICES


- **Hydraulic cylinder (A)**: raises and lowers the deck of the "Drop floor" device.



HOW TO UNFLOOD THE FEEDING UNIT

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Act on the controls of the electronic control system to activate the controls of the "Drop floor" device.
3. Activate the lever **(A)** of the tractor's hydraulic control valve (from position **1** to position **2**) to lower the deck of the "Drop floor" device **(B)** and obtain the clogging removal of the feeding unit.
4. Activate the lever **(A)** to bring the deck of the "Drop floor" device to the "high" position. The electronic control system will signal when the position has been reached.
5. Act on the controls of the electronic control system to de-activate the controls of the "Drop floor" device.
6. Activate the PTO to check if the feeding unit has unclogged.




IDM-217240-0400.pdf

**Page intentionally left
without information**

GENERAL DESCRIPTION

The feeding unit "with simple feeder" conveys the harvested product into the baling chamber. It is particularly suitable for harvesting fine-limbed and high-grade products, where it is necessary to protect the leaf structure.


- Feeding platform **(A)**: the product that is transported from the pick-up unit is deposited on this platform.
- Feeding forks **(B)**: they transfer the product from the feeding platform to the baling chamber.




PRODUCT CLOGGING REMOVAL IN THE FEEDING UNIT

Follow the instructions.

- 1-** Make sure tractor PTO is disengaged.
- 2-** Stop the engine, apply the parking brake and disengage the ignition key.
- 3-** Remove the product that clogs the feeding unit (**A**) by using the specific tool (**B**).
- 4-** Restart the motor of the tractor.
- 5-** Activate the PTO to check if the feeding unit has unclogged.
If the feeding unit has not unclogged, immediately deactivate the PTO.




- 6-** Place the lever (**C**) in position 1 and do not release it until the completion of the bale unloading operation.
- 7-** Switch off the engine of the tractor, and then disengage the ignition key.
- 8-** Open the cover (**D**).
- 9-** Close the cock (**E**) to assure safety conditions.
- 10-** Remove the product that clogs the feeding unit by using the specific tool (**B**).
- 11-** Check the condition of the safety bolt and, if necessary, replace it (See "How to replace the safety bolt").
- 12-** Open the cock (**E**).
- 13-** Close the cover (**D**).
- 14-** Restart the motor of the tractor.
- 15-** Place the lever (**C**) of the hydraulic control valve in the tractor in position 2 to close the tail gate.
- 16-** Activate the PTO to check if the feeding unit has unclogged.



HOW TO REPLACE THE SAFETY BOLT

Follow the instructions.

- 1-** Make sure tractor PTO is disengaged.
- 2-** Stop the engine, apply the parking brake and disengage the ignition key.
- 3-** Remove the product that clogs the feeding unit by using the specific tool (See "Product clogging removal in the feeding unit").
- 4-** Remove the damaged parts of the safety bolts (**F**).
- 5-** Rotate the shaft (**C**) to align the holes in the hub (**D**) with the holes in the pinion (**E**).
- 6-** Assemble the new safety bolt (**F**).



**Page intentionally left
without information**


GENERAL DESCRIPTION

The net binder unit quickly winds the bale up to the edges so that it becomes solid and compact.

For further information about programming and operation modes, etc. of the binder unit, see the part about the electronic control system.


The figure shows the path of the net during bale binding operations.

- **Support (A)**: it supports the net reel (A1).
- **Braking device (B)**: it keeps the net reel (A1) tightened during the binding operations.
- **Net driving rollers (C)**: at the beginning of the binding operation, they introduce the net into the baling chamber. The dancing roller (C2) keeps pressed against the motorised roller (C1) in a way to assure the correct drawing of the net.
- **Brush (D)**: it cleans the rubber roller (C1) from product debris.
- **Cutting device (E)**: it automatically cuts the net at the end of the binding cycle, according to the parameters that have been set by means of the electronic control system.
- **Reset device (F)**: it automatically restores the cutting device (E) every time the tail gate is opened to unload the bale.



ELECTRICAL DEVICES


- Electro-clutch (A)**: it drives the rubber roller to draw the net into the baling chamber.
- Sensor (S1)**: by means of the cam, it detects the quantity of unrolled net and, after the binding cycle has begun (net taken from the bale), it will stop the electro-clutch (A).
- Sensor (S4)**: it detects the end of the binding cycle.



NET REEL SUPPLY

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Open guards (A-B).
4. Lift the braking device (C) until it locks.
5. Remove split pin (D1) and remove pin (D).
6. Rotate the reel support (E) and disengage the knob (F1) from the reel support (E) to remove the catch (F).
7. Replace the reel.
8. Remove the catch (F) and insert the knob (F1).
9. Position the support (E) with the new reel.
10. Reintroduce pin (D) and split pin (D1).
11. Check that the reel is centred with respect to the baling chamber and, if necessary, adjust its position.
To centre to reel, disengage the knobs (F1) from the catches (F), manually move the reel and re-insert the knobs (F1) to block the catches (F).



Important

To make sure that the net unwinds in a correct way, check that the carton core of the reel is in good conditions (without damages and/or wet areas).


12. Unwind the net along the path that is specified in the figure, and then introduce the net into the specific driving rollers (G-L).
To assure an effective catch of the net to the bale, stretch the initial part of the net for at least 50 cm.
13. Rotate the handle (H) in clockwise direction (a full turn) in order to introduce a sufficient quantity of net (about 20 cm) to assure it is caught.
14. Lower the braking device (C).
15. Close guards (A-B).

 Important

If, during the binding operation, the net tends to spread in an excessive way, modify the unwinding direction (see the picture, path (X)).

If the net keeps unused between the rollers (G-L) for a long period, before re-starting the working activity, it is advisable to slightly rotate the handle (H) to allow detaching the net from the rubber roller (G).

In these conditions, you can see a mark on the rubber roller (G), which is caused by the pressure exercised by the roller (L). This inconvenience is not worrying, as the rubber roller (G) can restore the evenness of the surface after a few binding operations.




HOW TO ADJUST THE BRAKING DEVICE

In order to operate properly, the braking device must be leant against the reel.

If the braking action proves to be unsuitable, follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Open guards (A-B).
4. Use the holes that have been pre-arranged on the bracket (D) with respect to the pivot (D1) in order to modify its position, and so achieve a different braking action.
5. Repeat the operation in the other bracket.
6. Close guards (A-B).




HOW TO ADJUST THE PRESSURE OF THE NET DRIVING ROLLERS

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Open the cover (A).
4. By means of the screw (B) and the screws (B1) (and the relevant locknuts), adjust the pressure of the springs (C).

⚠ Important
 To properly adjust the springs, it is advisable to set the lengths (L-L1) at the measures that are specified in the picture.


5. Close the cover (A).



HOW TO ADJUST THE CUT RESET DEVICE

Follow the instructions.


1. Stop the tractor without turning off the motor, engage the parking brake, and then disconnect the power take-off.
2. Place lever **(D)** of the hydraulic control valve in the tractor in position **1** to open the tail gate.
3. Switch off the engine of the tractor, and then disengage the ignition key.
4. Open the cover **(A)**.
The hooks **(B)** are completely lifted.
5. Use the nuts **(C)** until the arm **(E)** and the lever **(F)** are at 3 mm (see figure).
6. Definitively tighten nuts **(C)**.
7. Close the cover **(A)**.
8. Start the engine of the tractor from the driver's seat.
9. Place the lever **(D)** of the hydraulic control valve in the tractor in position **2** to close the tail gate.




HOW TO DEACTIVATE AND ACTIVATE THE CUTTING DEVICE

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Open the cover **(A)**.



4. Remove the split pin (B), introduce the pivot (C) in the SAFETY POSITION, and then introduce the split pin.
5. Perform the necessary operations.
To re-activate the cutting device at the end of the aforesaid operations, remove the split pin (B), introduce the pivot (C) in the WORKING POSITION, and then introduce the split pin.
6. Close the cover (A).



HOW TO CLEAN THE NET DRIVING ROLLERS

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.

Before performing operations within the binder area, deactivate the cutting device in order to avert the dangers of shearing to the upper limbs in case of accidental activation, and pay attention to the cutting devices.


3. Open guards (A-B).
4. Deactivate the cutting device (See "How to deactivate and activate the cutting device").
5. Lift the strap (C).
6. Rotate the handle (D).
7. Clean and remove product debris from the net driving rollers (E-E1).
8. Spread a specific product (for example, talc) over the roller (E1) to prevent the deterioration of the surfaces and favour the detachment of the net.



Caution Precaution

To prevent damages to the rubber roller, do not use sharp or cutting objects.

9. Close guards (A-B).




HOW TO REPLACE THE ELECTRO-CLUTCH BELT

Follow the instructions.

 Important
This operation must be carried out with the help of an assistant.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Open guards (A-B).
4. Unscrew the screw (C) to loosen the tightener (D).
5. Unscrew the screw (E).
6. Remove the belt (F) and replace it with an original spare part.
7. Screw the screw (E).
8. Regulate the tightener (D) to adjust the tension of the belt.
Screw the screw (C).
9. Close guards (A-B).



IDM-21720801101.pdf


**Page intentionally left
without information**

GENERAL DESCRIPTION

The twine binder unit binds the bale with spiral-shaped twine wrapping, so that the bale becomes solid and compact.

For further information about programming and operation modes, etc. of the binder unit, see the part about the electronic control system.


- **Twine guiding arm (A)**: it distributes the twine over the bale in simultaneous and opposed way with respect to the other twine guiding arm. The electronic control system sets the winding mode and the quantity of twine.
- **Cutting arm (B)**: it automatically cuts the twine at the end of the binding operation.
- **Transmission unit (C)**: it conveys the simultaneous and opposed motion to the twine guiding arms (A) by means of the gearmotor.
- **Twine case (D)**: it contains several twine reels that are connected together in a way to work with an extended operating range.



IDM-2172090102.pdf

ELECTRICAL DEVICES

- **Electric motor (A):** it conveys motion to the twine guiding arms.
- **Sensor (B):** indicates the position of the twine guide.
- **Sensor (C):** it detects the rotation of the pulley to determine the quantity of twine being wound around the bale.




IDM-2172080802.pdf

HOW TO INTRODUCE THE TWINE

This operation should be performed only the first time that the machine is started. In order not to have to repeat this operation, supply the reels before they completely run out of twine.


Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Open guards **(A-B-C)**.
4. Unscrew the nut **(G)**, remove the hitch pin **(H)** and open the twine case **(L)** (Perform the operation only with front twine box).




IDM-2172080802.pdf

5. Unwind the twines (**F1-F2**) by following the path that is specified in the figure.
6. Introduce the twine (**F1**) into the twine guide arm (**D1**) by using the specific tool (**E**).
To complete the introduction of the twine, completely introduce the tool (**E**).



IDM-21720900302.pdf


7. Overlap the twine guiding arms (**D1-D2**) one to the other (See "Electronic control system").
8. Deactivate the electronic control system.
9. Pull the twine (**F1**) and extract about 25÷30 cm from the twine guiding arm (**D1**).
When introducing the twine, leave about 35 cm of additional wire in the area to prevent that the twine returns and does not catch the bale during the movement of the arms.
10. Reactivate the electronic control system.




IDM-21720900402.pdf

IDM 217-209-5.fm

11. Adjust the twine guide arms (D1-D2) into the initial position (See "Electronic control system").
12. Remove the tool (E).
13. Repeat the same operation to introduce the twine (F2) into the twine guiding arm (D2).
14. Adjust the twine tightening clamps (See "How to adjust the twine tightening clamps").
15. At the end of the operation, position the twine guiding arms into the point where the binding cycle starts (See "Electronic control system").
16. Put away the tool (E).



17. Close the twine case (L), introduce the hitch pin (H), and then screw the nut (G) (Perform the operation only with front twine box).
18. Close guards (A-B-C).



HOW TO SUPPLY THE TWINE REELS

Prevent the machine from completely running out of twine reels, so that you do not have to repeat the twine introduction operation. Periodically (every 4÷6 hours or at the end of the working day), check that the twine case is supplied with twine reels.

Follow the instructions.


Carry out the following procedure from the ground, without getting onto machine parts.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.

3. Open guards.
4. Introduce the new reels into the twine box (**G-G1-G2-G3**) instead of the finished ones, and then connect them together.
The twine box can be side or front type.
If there is a front twine box, first introduce the rear reels.


 Important

To prevent the twine from unwinding in a helical way, the reels must be positioned with the wordings on the package in vertical position (not overturned).



IDM-21720901801.pdf

The reels (A1-A2-A3) feed the twine guiding arm (D1), while the reels (B1-B2-B3) feed the twine guiding arm (D2).




5. In order to connect them, knot the upper end of a reel with the lower end of the following reel.



Important

In order to make sliding easier and to prevent entanglement, connect the end of the twine as specified in the figure, and make sure that the knot is as smaller as possible.


6. Close guards.



HOW TO ADJUST THE TWINE TIGHTENING CLAMPS

Follow the instructions.

1. Make sure tractor PTO is disengaged.
 2. Stop the engine, apply the parking brake and disengage the ignition key.
 3. Open the cover (A).
 4. Adjust the tightening of the springs (C) by using the nuts (B).
- To make sure that the twines (F1-F2) slide freely, apply a force equalling 20÷30 N.
5. Close the cover (A).



HOW TO ADJUST THE CHAINS OF THE TWINE GUIDING ARMS

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.
3. Open guards (A-B).
4. Unscrew the nut (C), remove the hitch pin (D) and open the twine case (E) (Perform the operation only with front twine box).
5. Loosen screws (F).
6. Operate on the support (G) to adjust the tension of the chain (H).

i Important


To position the twine guide arms in a correct way, the supporting surfaces (S1-S2) of the support (G) and of the frame (L) must be parallel.

Do not tension the drive too much in order not to damage the rotating devices.

7. Tighten screws (F).
8. Close the twine case (E), introduce the hitch pin (D), and then screw the nut (C) (Perform the operation only with front twine box).
9. Close guards (A-B).

i Important

In order to obtain good performances of the binder unit, perform periodical controls to keep all operating areas suitably clean.



HOW TO REPLACE THE BLADE

Follow the instructions.

1. Make sure tractor PTO is disengaged.
2. Stop the engine, apply the parking brake and disengage the ignition key.



Caution Precaution

Wear protection gloves in order to avoid the risk of cutting your hands.


3. Open guards (A-B).
4. Unscrew the nut (C), remove the hitch pin (D) and open the twine case (E) (Perform the operation only with front twine box).




Important

Before disassembling the support (G) of the blade, mark the area that enters into contact with the structure of the cutting arm, in such a way as to identify the position and the correct coupling during the re-assembly operations.

5. Unscrew the screws (F) to remove the support (G).
6. Unscrew the screws (H) to disassemble the worn blade (L).
7. Assemble the new blade and fasten it with the screws (H) (comply with the dimension that is specified in the picture).
8. Assemble the support (G) again in the previous position, and then fasten it using the specific screws.
9. Close the twine case (E), introduce the hitch pin (D), and then screw the nut (C) (Perform the operation only with front twine box).
10. Close guards (A-B).



IDM-21720801302.pdf




IDM-21720801402.pdf

Table 1: components of the electrical system

<i>Abbreviation</i>	<i>Name</i>	<i>photo no.</i>
BCT	Control unit	1
CN	Electro-clutch	8
ECU	Control unit	2
HL	Left hook sensor	14
HR	Right hook sensor	3
MF	Feeding motor	11
MT	twine binding motor	9
PB	Bale diameter potentiometer	15
PF	Potentiometer of the direction indicators	16
S2	Reset/start position sensor	13
SB	Twine binding end sensor	9
SC	Supercut sensor	4
SD	"Drop floor" sensor	5
SF	Feeding motor sensor	11
SK	Net knife sensor	10
SM	Bale maximum diameter sensor	15
SN	Net count sensor	12
SP	Twine binder pulley sensor	6
ST	Twine binder motor sensor	9
V0	By-pass solenoid valve	17
VD	"Drop floor" solenoid valve	7
VP	Pick-up solenoid valve	7
VS	Supercut solenoid valve	7
VR	Proportional solenoid valve for hydraulic lock	17

ELECTRICAL COMPONENTS DIAGRAMESD **A01**

	order information	length (mm)	use for:
	SPAREPARTS IGE RV41		
45	VNB0567973 PILOTEX FOCUS2		
46	VNB0548173 CLAMP SET	7000	8
47	MT00001658 POWER CABLE	8000	5
48	MT00001659 CAN CABLE		1,2,3,16 17,21,23 30,37
49	MT00000957 CABLE SENSOR 90 DEGR	5000	
50	MT00001720 CABLE SENSOR 90 DEGR WITH TUBE	3000	24, 31
51	MT00000914 CABLE SENSOR	5000	4,40,41
52	MT00001548 SENSOR M12		13,18,19 22,42,43
53	MT00001549 SENSOR M18		12,25,26 32,33,38
54	MT00001577 SENSOR ASSY ANGLE 90DEG	1500	9
55	MT00001579 SENSOR ASSY ANGLE 90DEG	5700	10
56	MT00000476 CABLE VALVE LED	1000	27,28,29 34,35,36 39
57	MT00001660 CABLE VALVE LED	3000	6,7
58	MT00001570 CABLE CLUTCH	800	20
59	MT00001722 SET COVER VALVE CONNECTOR 18MM		6,7
60	MT00000723 SET 10X M12 GLAND+NUT+PLUG		
61	MT00000724 SET 10X M16 GLAND+NUT+PLUG		
62	MT00000726 SET 10X M25 GLAND+NUT+PLUG		
63	MT00001733 PCB IGE VI.02		




SPARE PARTS

IDM-483004012301.pdf

ELECTRICAL COMPONENTS SPARE PARTS DIAGRAM

ESD **A02**




IDM_485-004-0 -

IDM_48300401300.pdf

"CONTROL UNIT" DRILLING DIAGRAM (ECU)

ESD **A03**





IDM-4830001-000.pdf

IDM-483-004-0

"CONTROL UNIT" WIRING DIAGRAM AND DECALCOMANIA (ECU)

ESD **A04**

LINKS			VERBINDING			RECHTS	
connector	pos	contact	kabel	kleur	lengte	contact	function
	3			orange	8 mtr		ON SW
	4			yellow			CAN H
	5			green			GND
	6			blue			CAN L
	7			black			PWR




IDM-48300101800.pdf

IDM-483-004-0

CAN CABLE

ESD **A05**

LINKS			VERBINDING			RECHTS	
connector	pos	contact	kabel	kleur	lengte	contact	function
	+	soldeer		brown	7 mtr		ACT PWR
	-	soldeer		blue			ACT GRND




IDM-483001015900.pdf

IDM-483-004-0-

SUPPLY CABLE

ESD **A06**

connector	contact	kabel	kleur	lengte	contact	function
			brown	0,8 mtr		power
			blue			ground




IDM-4830102000.pdf

IDM-483-004-0

ELECTRO-CLUTCH CABLE


ESD **A07**

LINKS	VERBINDING			RECHTS	
sensor	kabel	kleur	lengte	contact	function
	kabel inkorten	brown	1,4 mtr		+
		black			S
		blue			-



-  ← magneethouder+magnet
-  ← 4x bout M5x20 - KG00494000
-  ← 4x nyloc moer M5 - KG01069700
-  ← 4x ring M5 - KG01263700

sensor	kabel A		kabel B		contact	function
	lengte	kleur	kleur	lengte		
2,5 mtr kabel van de sensor		brown	brown	3,2 mtr		+
		black	black			S
		blue	blue			-



-  magneethouder+magnet
-  4x bout M5x20 - KG00494000
-  4x nyloc moer M5 - KG01069700
-  4x ring M5 - KG01263700


IDM-48300401580.pdf

IDM-483-004-0-

DIRECTION INDICATOR CABLE

ESD **A09**

	kleur	lengte
power	brown	inkorten naar 1,5 mtr
S	black	
ground	blue	




IDM-48300102300.pdf

IDM-483-004-0

SENSOR CABLE 0°

ESD **A10**

contact	kleur	lengte	sensor kabel	function
	brown			+
	black			S
	blue			-




IDM-48300102400.pdf

IDM-483-004-0-

SENSOR CABLE 90°

ESD **A11**

connector + kabel	nummer	lengte	contact	function
	1	3 mtr		
	2			




IDM-483001026500.pdf

IDM-483-004-0-


SOLENOID VALVE CABLE

ESD **A12**




Picture 2

ECU




Picture 1

BCT




Picture 3

HR




Picture 4

SC








Picture 5







SD






PICTURE



IDM-483001006500.pdf




IDM-483001006900.pdf



IDM-4830001000.pdf

IDM-483-004-0-

PICTURE



IDM-4830901B00.pdf

Table 2: hydraulic system index

Ref.	Tab.	Code	Name
L1	HSD A01	-	Hydraulic system diagram for machines with simple feeder and fixed pick-up
L+M+N	HSD A02	-	Hydraulic system diagram of the machines with rotating feeder (with "Drop Floor") and fastened pick-up
N	HSD A03	3444248	Rotor hydraulic unit with "Drop floor"
H+H1+H2	HSD A04	-	Gate/bale density hydraulic system diagram
H2	HSD A05	3944256	Hydraulic lock for tail gate/bale density


Table 3: components of the hydraulic system

<i>Ref.</i>	<i>Technical specifications</i>	<i>Name</i>	<i>Reference to the table HSD A00</i>
T		Tractor control valve	
2a		Tractor single-acting control valve (pick-up)	
4		Safety cock	
5		Knife operating jacks	L1

IDM 4ES-004-0

HYDRAULIC SYSTEM DIAGRAM FOR MACHINES WITH SIMPLE FEEDER AND FIXED PICK-UP

HSD **A01**



IDM-4830401730.pdf

IDM-483-004-0-


HSD **A01**

Table 4: components of the hydraulic system

<i>Ref.</i>	<i>Technical specifications</i>	<i>Name</i>	<i>Reference to the table HSD A00</i>
T		Tractor control valve	
2a		Tractor single-acting control valve (pick-up)	
3		Pick-up solenoid valve	
4		Safety cock	
5		"Drop floor" actuating jacks	M
9		Knife operating jacks	L
11		Hydraulic lock (3444248)	N

HYDRAULIC SYSTEM DIAGRAM OF THE MACHINES WITH ROTATING FEEDER (WITH "DROP FLOOR") AND FASTENED PICK-UP


HSD **A02**




IDM 483-004-0

IDM-48300401820.pdf

HSD **A02**



Dettaglio porte A e B



Attacchi:

A - B = G 1/4" (Predisposizione per valvola strozzatrice)

P = G 1/4"

Materiale:

Corpo : Alluminio

Particolari Interni : Acciaio omt. imp. rettificati

Guarnizioni

Materiale: BUNA N 70 Sh

Temperatura d'esercizio: -20 °C / +90° C

Caratteristiche:

Tensione di alimentazione: 12 Vcc

Portata: 3 l/min

Pressione: 210 bar

Fluido : olio minerale 20 - 200 cSt

Viscosità : 46 cSt a 40°C

Filtraggio : 25 micron nominali

Valvole:

1 = EL10B/10PB

IDM-48320/031200.pdf

ROTOR HYDRAULIC UNIT WITH "DROP FLOOR"

HSD A03


Table 7: components of the hydraulic system


<i>Ref.</i>	<i>Technical specifications</i>	<i>Name</i>	<i>Reference to the table HSD A00</i>
1		Bale density jack (right side)	H1
2		Bale density jack (left side)	H1
3		Single-acting stop valve	
4		Gate jack (right side)	H
5		Gate jack (left side)	H
6		Safety cock	
7	2,0	Single-acting throttle valve	
8		Pressure gauge	
9	1,0	Single-acting throttle valve	
10		Hydraulic lock for tail gate/bale density	H2
11		By-pass solenoid valve	
12	2,5	Single-acting throttle valve	
13		Filter	

IDM 483-004-0 -

GATE/BALE DENSITY HYDRAULIC SYSTEM DIAGRAM

HSD **A04**





IDM-4830402100.pdf

TAIL GATE/BALE DENSITY HYDRAULIC CONTROL VALVE

HSD **A05**

A

- Allowable slopes
General information about the machine 30
- Areas of danger
General information about the machine 21
- Assistance, request procedure
General and safety information 5
- Attached documentation
General and safety information 5

B

- Bale density/diameter cable
Attachments 134

C

- CAN cable
Attachments 131
- Change of reduction gear oil
General information about the machine 67
- Check of belt alignment
General information about the machine 67
- Cycle, operation
General information about the machine 18
- "Control unit" drilling diagram (ECU)
Attachments 129
- "Control unit" wiring diagram and decalcomania (ECU)
Attachments 130

D

- Description of safety signs
General and safety information 11
- Direction indicator cable
Attachments 135
- Driving torque table
General information about the machine 65

E

- Electrical components diagram
Attachments 126
- Electrical components spare parts diagram
Attachments 128
- Electrical devices
Feeding unit (rotor) 102
Net binder unit (electronic) 110
Twine binder unit (electronic) 118
- Electro-clutch cable
Attachments 133
- Electronic and electric devices
General information about the machine 36
- Environmental impact, safety regulations
General and safety information 11
- Equipment
General information about the machine 30

F

- Fittings on demand
General information about the machine 32

G

- Gate/bale density hydraulic system diagram
Attachments 150
- General description
Feeding unit (rotor) 101
Net binder unit (electronic) 109
Pick-up unit (extra-large type) 95
Pick-up unit (wide type) 87
Product feeding unit (with simple feeder) 105
Twine binder unit (electronic) 117
- General description of the machine
General information about the machine 15
- General safety rules
General and safety information 6
- Glossary and terminology
General and safety information 5

H

- How to adjust belt alignment
General information about the machine 58
- How to adjust centralised lubrication
General information about the machine 57
- How to adjust the braking device
Net binder unit (electronic) 112
- How to adjust the chains of the twine guiding arms
Twine binder unit (electronic) 123
- How to adjust the cleaning rollers
General information about the machine 60
- How to adjust the cut reset device
Net binder unit (electronic) 113
- How to adjust the fixed baffle plate
Pick-up unit (wide type) 90
- How to adjust the height of the pick-up unit
Pick-up unit (extra-large type) 98
Pick-up unit (wide type) 90
- How to adjust the pick-up transmission chain
Pick-up unit (extra-large type) 99
Pick-up unit (wide type) 92
- How to adjust the pressure of the net driving rollers
Net binder unit (electronic) 112
- How to adjust the tilting baffle plate
Pick-up unit (extra-large type) 98
Pick-up unit (wide type) 91
- How to adjust the twine tightening clamps
Twine binder unit (electronic) 123
- How to adjust transmission chains
General information about the machine 57
- How to balance the pick-up unit
Pick-up unit (extra-large type) 97
Pick-up unit (wide type) 89
- How to clean the belt guiding rollers
General information about the machine 68
- How to clean the net driving rollers
Net binder unit (electronic) 114
- How to couple the machine to the tractor
General information about the machine 47

How to deactivate and activate the cutting device
Net binder unit (electronic) 113

How to handle the pick-up unit
Pick-up unit (extra-large type) 96
Pick-up unit (wide type) 88

How to introduce the twine
Twine binder unit (electronic) 118

How to open the guards
General information about the machine 51

How to remove product clogging in the pick-up unit
Pick-up unit (extra-large type) 97
Pick-up unit (wide type) 89

How to replace the belts of the baling chamber
General information about the machine 73

How to replace the blade
Twine binder unit (electronic) 124

How to replace the electro-clutch belt
Net binder unit (electronic) 115

How to replace the safety bolt
Pick-up unit (wide type) 93
Product feeding unit (with simple feeder) 107

How to replace the tyres
General information about the machine 72

How to set bale density
General information about the machine 54

How to set bale diameter
General information about the machine 54

How to set the height of the drawbar
General information about the machine 42

How to set the length of the cardan shaft
General information about the machine 43

How to store the machine at season end
General information about the machine 70

How to supply the twine reels
Twine binder unit (electronic) 120

How to uncouple the machine from the tractor
General information about the machine 49

How to unflood the feeding unit
Feeding unit (rotor) 103

Hydraulic system
Attachments 143

Hydraulic system diagram for machines with simple feeder and fixed pick-up
Attachments 144

Hydraulic system diagram of the machines with rotating feeder (with "Drop Floor") and fastened pick-up
Attachments 146

I

Improper use
General information about the machine 20

Instructions and suggestions for use
General information about the machine 51

Instructions for handling and loading
General information about the machine 39

Instructions for maintenance
General information about the machine 61

Instructions for part replacement
General information about the machine 71

Instructions for use and operation
General information about the machine 46

L

Loading and unloading
General information about the machine 39

Lubricant table
General information about the machine 64

Lubrication points diagram
General information about the machine 65

Lubrication, diagram of points
General information about the machine 65

M

Machine demolition
General information about the machine 80

Machine disposal
General information about the machine 80

Machine, dismantling
General information about the machine 80

Machine, disposal
General information about the machine 80

Machine, general description
General information about the machine 15

Machine-tractor combination
General information about the machine 41

Maintenance, instructions for
General information about the machine 61

Manual equipment for vice ("MATO" type junctions)
General information about the machine 74

Manufacturer and machine identification
General and safety information 4

Manufacturer and machine, identification
General and safety information 4

N

Net reel supply
Net binder unit (electronic) 110

Night work
General information about the machine 21

O

Oil supply for centralised lubrication
General information about the machine 68

Oil-pressure devices
Feeding unit (rotor) 102
General information about the machine 35
Pick-up unit (extra-large type) 96
Pick-up unit (wide type) 88

Operation and use, instructions for
General information about the machine 46

Operation cycle
General information about the machine 18

P

- Packing and unpacking
General information about the machine 39
- Part replacement, instructions for
General information about the machine 71
- Picture
Attachments 139
- Position of information and safety plates
General information about the machine 37
- Procedure to request technical assistance
General and safety information. 5
- Product clogging removal in the feeding unit
Product feeding unit (with simple feeder) 106
- Programmed maintenance intervals chart
General information about the machine 61
- Purpose of this manual
General and safety information 3
- Putting the machine into service
General information about the machine 71

R

- Residual risks
General information about the machine 20
- Road circulation
General information about the machine 56
- Rotor hydraulic unit with "Drop floor"
Attachments 148

S

- Safety devices
General information about the machine 33
- Safety rules about loading and transport operations
General and safety information 6
- Safety rules about maintenance and adjustments
General and safety information 10
- Safety rules about road circulation
General and safety information 9
- Safety rules about use and operation
General and safety information 7
- Safety rules for the environmental impact
General and safety information 11
- Safety signs, description
General and safety information 11
- Safety, devices
General information about the machine 33
- Sensor cable 0°
Attachments 136
- Sensor cable 90°
Attachments 137
- Solenoid valve cable
Attachments 138
- Special maintenance
General information about the machine 71


- Supply cable
Attachments 132

T

- Tail gate/bale density hydraulic control valve
Attachments 152
- Technical data RV 4116 F
General information about the machine 22
- Technical data RV 4116 R
General information about the machine 24
- Technical data RV 4118 F
General information about the machine 26
- Technical data RV 4118 R
General information about the machine 28
- Terminologies and glossary
General and safety information 5
- Troubles, causes, remedies
Failure information 81

U

- Unpacking and packing
General information about the machine 39
- Use and operation, instructions for
General information about the machine 46
- User's manual
General and safety information 4



FOCUS

Operation and maintenance manual

Edition	05/2011
Printing date	xxx
Language	GB
Series	xxx
Serial number	xxx
Code	9820D50GB

FOCUS

ELECTRONIC CONTROL SYSTEM

Keep this manual in a well-known and easily accessible place, in order to have it always at disposal when you need to read it.

The user and maintenance information, which is an integral part of agricultural machinery, MUST ALWAYS BE KEPT IN THE DRIVER'S SEAT of the tractor to which the machine is combined.

IMPORTANT: The text of the document is the translated version of the Italian manual (original language), identified by code number 9820D50IT

COM83-011-0.fm

Cod. 9820D50GB	Ed. 04/2011
I ► n.XXXXXX	► I
Per approvazione.....	

A

- Activation of binders in "manual mode" (18)
 - Activation of the twine/net insertion device* (19)
 - Activation of twine guide arms* (18)
- Activation of operating units in "manual mode" (19)
- Assistance, request procedure (4)

B

- Bale binding in "automatic mode" (20)
 - Net binding* (20)
 - Twine binding* (20)
- Bale binding in "manual mode" (21)
 - Net binding* (21)
 - Twine binding* (21)

C

- Causes, remedies, troubles (23)
- Connecting the equipment (8)
- Counter reset (22)

D

- Description of controls (9)
- Description of the icons of the "Control bar" (11)
 - List of the "Set-up" screen page icons* (11)
 - List of work screen page icons* (11)
- Description of the screen page icons (14)
- Descrizione schema logico funzionale (6)
- Dismantling the equipment (22)

E

- Environmental impact, safety regulations (5)
- Equipment configuration at the first switching on (17)
- Equipment identification (4)
- Equipment operation troubleshooting (23)
- Equipment, general description (6)

G

- General description of the equipment (6)

M

- Maintenance recommendations (22)

P

- Parameter programming (16)
- Procedure to request technical assistance. (4)
- Programming the bale density (18)
- Programming the twine binding features (17)
- Purpose of this manual (3)

R

- Remedies, troubles, causes (23)

S

- Safety rules (4)
- Safety rules for the environmental impact (5)
- Safety, regulations (4)
- Schema logico funzionale, descrizione (6)

T

- Technical specifications (8)
- Terms and definitions (4)
- Troubles, causes, remedies (23)



PURPOSE OF THIS MANUAL

- This manual, which is an integral part of the equipment, has been implemented by the manufacturer to supply the information necessary to those who are trained and authorized to interact with it during its expected service life.
- The information contained in the manual must be completed with the one in the use and maintenance manual of the relating machine.
- As well as adopting good practices for use, the manual's intended readers must read it thoroughly and apply its instructions to the letter.
- All pieces of information are supplied in the Manufacturer's mother tongue (Italian) and they can be translated into other languages to meet trading and/or legislative needs.
- The translations in the language of the country of utilisation, provided by the manufacturer, have been carried out directly from the "ORIGINAL INSTRUCTIONS".
If the translations are realised by the mandatory agent or whoever issues the machine in the linguistic zone in consideration, they must carry out the translation starting from the original instructions and the following writing must be shown: "TRANSLATION FROM THE ORIGINAL INSTRUCTIONS".
- This information makes the operator aware of the need to take special care to avoid accidents. There is no substitute for caution. Safety is responsibility of all operators who use the machine during its operation life.

Carefully read the instructions in the supplied manual and make sure you follow them thoroughly, above all those concerning safety.

- Dedicate a bit of time to read the instructions to prevent unpleasant accidents. When an accident occurs, it is too late to remember that you had to behave differently.

Keep this manual in a well-known and easily accessible place, in order to have it always at disposal when you need to read it.

To easily find out the specific topics of interest, read the table of contents and the index.

- The manufacturer reserves the right to modify the manual without the duty to previously communicate it, provided that it does not compromise the health and the safety of operators.
- To highlight certain essential parts of the text and to indicate important specifications, several symbols have been adopted.

Danger Warning

Indicates extremely dangerous situations that, if disregarded, may seriously endanger the health and safety of persons.

Caution Precaution

Indicates that suitable practices must be adopted to avoid the risk of injuries and damages.


Important

Indicates particularly important technical information that should not be disregarded

EQUIPMENT IDENTIFICATION

The displayed identification plate is directly installed on the equipment. It specifies traceability instructions and references for the request of technical support.

- A) Number and production lot
- B) Equipment spare part code



PROCEDURE TO REQUEST TECHNICAL ASSISTANCE.

In case of need, please apply to the manufacturer's Technical Assistance Service.

For each service request indicate the details carried on the identification plate, the approximate hours of use and type of defect found.

TERMS AND DEFINITIONS

A few terms which are widely used in the manual are described below to better explain their meaning.

- **Operator:** person that has been selected and authorised among the personnel who have the qualifications, the competences and the knowledge that are necessary to drive the tractor to which the machine is coupled, and who are also capable of performing the production activity autonomously, as well as in an adequate, correct and riskless way.
- **Skilled technician:** a person authorised and chosen from those who have the requirements, skills and information necessary for handling (loading and unloading), installation, connection and precision adjustment operations of the equipment.

SAFETY RULES

- In addition to being trained and informed on the how to use the machine, the operator must possess the necessary skills and expertise for the type of work to be carried out.
- All assembling and disassembling of the equipment from the operating machine must be carried out with the tractor turned off.
- The machine must be used only for the purposes provided for by the Manufacturer. An improper use of the machine can endanger people's safety and lead to economic losses.
- All the repair interventions must be performed exclusively by qualified personnel with certified experience, acquired in the specific intervention sector.

- To carry out tests on the output devices, which may cause sudden movements of dangerous parts, ensure that safety conditions are adequate for yourself and others in accordance with the laws in force on the subject of safety in the workplace.

SAFETY RULES FOR THE ENVIRONMENTAL IMPACT

- The Waste of Electrical and Electronic Equipment may contain dangerous substances with potentially harmful effects on the environment and on people. It is recommended to correctly dispose them.
- When the machine is dismantled, select all components according to their chemical characteristics and collect them separately in compliance with the relevant laws.
- With reference to the WEEE directive (Waste of Electrical and Electronic Equipment), during dismantling, the user must separate the electrical and the electronic components and dispose them in the appropriate authorized collection centres or give them back as they are to the seller, when a new purchase is made.



All the components, which must be separated and disposed of in a specific manner, are marked with a special mark.

- The unauthorized disposal of Waste of Electrical and Electronic Equipment (WEEE) is subject to fine according to sanctions regulated by the laws in force in the territory where the infraction has been verified.
- As implementation of the European directives (2002/95/CE, 2002/96/CE, 2003/108/CE) in the Italian territory, for example, a law decree (n. 151 dated July 25 2005) has been enacted, thus providing for an administrative fine of 2000÷5000.

GENERAL DESCRIPTION OF THE EQUIPMENT


- The electronic control system "FOCUS" was designed and manufactured to program and control the production activity of the reference machine.
- This equipment must be properly installed in the driver's seat to be used by the driver, who must be adequately skilled to drive and use the machine in safe conditions.

Description of the operating logic diagram

The figure shows the screen pages that make up the operating terminal and the list includes the description of the functions that can be displayed and/or programmed.


Some screen pages of the operating logic diagram may appear in different displays.

In the screen pages that appear in different displays, the operating logic diagram is at the beginning of the paragraph.



IDM-48301104300.tif

- 1) "Set-up" screen page
- 2) "Configuration" screen page
- 2a) "Formats & units" screen page
- 3) "Troubleshooting" screen page
- 3a) "Memory" screen page
- 3b) "Test" screen page



IDM-46301104400.tif

- 4) "Lock Screen" screen page
- 5) "Work 1" screen page
- 5a) "Work 2" screen page
- 6) "Binding programmes" screen page
- 7) "Partial counter" screen page
- 7a) "Total counter" screen page
- 8) "Bale density" screen page
- 9) "Farmer 1" screen page
- 9a) "Farmer 2" screen page
- 9b) "Farmer 3" screen page
- 10) Control bar: it is shown on all screen pages and it displays the active icons only.

TECHNICAL SPECIFICATIONS


Table 1: Technical data of equipment

Description	Unit of measurement	Value
Display		
Type		LCD monochrome display
Size	mm (inch)	-
Display resolution	pixels	320 x 240
Data transmission		
Serial type		RS232 DB9
CAN type		CANBUS IN/OUT
Technical specifications		
Size	mm	250x160x70
Weight	kg	0,95
Supply voltage	V	9÷14 Vdc
Absorbed power	W	-
Protection degree (front)		IP65
Working temperature	°C	-10÷60
Humidity (without condensate)		10÷90%

CONNECTING THE EQUIPMENT

To carry out this operation proceed as indicated.

- Install the equipment (**A**) on the special support inside the tractor cab.
- Run the cable from the tractor cab along the drawbar.
- Connect the equipment connector to the wiring (**B**) on the operating machine.
- This harness is supplied with a supply cable with a 3-pin plug (**C**) to be connected to the 3-pole socket (**D**) on the tractor, capable of providing up to 20 A of current to the equipment. Should it be lacking, the 3-pin socket supplied with the machine should be installed on the tractor. The + terminal of the 3-pin socket should be connected directly to the + pole of the battery through a cable having a section of at least 5 mm².



Caution **Precaution**

Check that the socket on the tractor is protected by a 20A fuse to prevent dangerous short circuits on the supply cable. Make sure that the tractor wheels and the cardan shaft cannot damage the equipment cable.

When the equipment is disconnected, close the wiring connectors with the special plugs supplied.

Important


Before starting work connect the plug to the socket on the tractor. Power must only be supplied to the machine as indicated.

Caution Precaution

Do not install non conforming fuses, do not modify the cables, and do not substitute plugs and sockets with others not similar to the original ones.

DESCRIPTION OF CONTROLS


The figure shows the equipment with the control devices.



The list specifies the main functions of each control and item in the equipment.

- A) Switch:** it is used to establish the operating conditions of the equipment.
 - **Position 0:** the equipment is off.
 - **Position 1:** the equipment is on.
- B) LCD display:** it displays the operating conditions of the production activity and the parameters that are necessary during programming operations.
- C) Buttons:** press them to regulate the contrast of display.




- D) **Buttons:** press them to regulate the sound level of the acoustic signal.
- E) **Buttons:** press them to activate the functions of "control bar".
- F) **Buttons:** press them to programme the numeric value of the parameter and to choose among the available options programmed by the manufacturer.
- G) **Buttons:** press them to select the previous or next programming area.
- H) **"OK" button:** press it to save the programmed values and to confirm the alarm messages.
- L) **"ESC" button:** press it to cancel the value modifications in programming area.
- M) **Button not enabled:**
- N) **Button:** press it to pass from the "Equipment set-up" screen pages to the "Equipment use" screen pages and vice versa.
- P) **Button not enabled:**



DESCRIPTION OF THE ICONS OF THE "CONTROL BAR"

The list includes the description of the icons in the different screen pages.

List of the "Set-up" screen page icons


- 
Icon: to display "Configuration" screen page.
- 
Icon: to display " Troubleshooting" screen page.
- 
Icon: to display "Set-up" screen page.
- 
Icons: to display next or previous screen page.
- 
Icons: to display next or previous card.
- 
Icon: to set the "Metric" system in all units of measurement.
- 
Icon: to set the "Imperial" system in all units of measurement.
- 
Icon: to set the "US" system in all units of measurement.
- 
Icon: to activate and deactivate the "Test" mode of the equipment buttons.

List of work screen page icons


- 
Icon: to display "Work screen page 1".
- 
Icon: to display "Lock Screen" screen page.



Icon: to display "Lock Screen" screen page.



Icons: to display next or previous card.




Icons: to display next or previous screen page.



Icon: to display next screen page.



Icon: to enable twine binding.



Icon: to enable net binding.



Icon: to display "Binding programmes" screen page.



Icon: to reset the length counter of the net used in the binding phase.



Icon: to start twine binding in "manual mode".



Icon: to start net binding in "manual mode".



Icon: to display "Partial counter" screen page.




Icon: to display "Bale density" screen page.



Icon: to display "Farmer" screen page.



Icons: to activate the opening or closing of twine guide arms.



Icons: to activate the opening or closing of twine/net insertion devices.



Icons: to enable the machine operating modes.



Icon: to select the operating unit to be activated (Knives / Drop floor / Pick-up).



Icon: to save the production counters of the selected card.



Icon: to reset the production counters.




Icon: to display "Total counter" screen page.



Icon: to display "Dealer" screen page.



Icon: to display "Service" screen page.



Icon: to display " Troubleshooting" screen page.




Icon: to display "ISOBUS parameter set-up" screen page.

DESCRIPTION OF THE SCREEN PAGE ICONS

The list includes the description of the icons in the different screen pages.



Icon: to display the number of produced bales.



Icon: to display the number of produced bales in one hour.



Icon: to display the length of the used net.



Icon: to programme the bale diameter (only for machine with variable chamber).



Graphic bar: to display the bale diameter (only for machine with variable chamber).
The graphic bar shows the reference values (minimum, programmed and maximum value).



Icon: to programme the bale pressure (only for machine with fixed chamber).



Graphic bar: to display the bale pressure (only for machine with fixed chamber).
The graphic bar shows the reference values (minimum, programmed and maximum value).



Icon: to display the selected operating unit (Knives / Drop floor / Pick-up).



Icons: to display the bale binding mode.



Icon: to display the driving information of the tractor to optimise bale pressing.
The higher the number of displayed arrows is, the higher the cell load unbalance of the baling chamber is.



Icon: to programme the number of binding turns of net binding.




Icon: to display the number of the binding programme.


- 


Icon: to programme the distance of external binding turns from the bale edge
- 


Icon: to programme the number of external binding turns.
- 

Icon: to programme the number of intermediate binding turns.
- 

Icon: to programme the number of internal binding turns.
- 


Icon: to display the daily production counter of the machine.
- 

Icon: to display the total production counter of the machine.
- 


Icon: to display the number of bales produced with twine binding and inserted knives.
- 

Icon: to display the number of bales produced with net binding and inserted knives.
- 

Icon: to display the number of bales produced with twine binding and removed knives.
- 

Icon: to display the number of bales produced with net binding and removed knives.
- 

Icon: to programme the time between the end of bale pressing and the beginning of the net binding.
- 

Icon: to programme the number of impulses in the net pre-injection phase.
- 


Icon: to activate the second attempt of net insertion.
- 


Icon: to programme the distance between the internal binding turns of twine binding.
- 

Icon: to activate the second attempt of twine insertion.

- 


Icon: to activate and programme the interval between two cleaning cycles of the machine.
- 

Icon: to programme the display time of the "stop" signal on display , at the beginning of the binding cycle.
- 

Icon: to programme the maximum difference between the diameters at the bale sides.
- 

Icon: to programme the correction factor of the bale diameter (only for machine with variable chamber).
- 


Icon: to activate or deactivate the acoustic signal during the tail gate opening.
- 

Icon: to activate or deactivate the acoustic signal during the tail gate closing.
- 

Icon: to activate or deactivate the acoustic signal when reaching 90% of bale pressing.
- 

Icon: to activate or deactivate the acoustic signal when starting the binding cycle.

PARAMETER PROGRAMMING



Follow the instructions.


1. Check the desired screen pages (one at a time), on which programming or value change shall be carried out.
2. Press buttons **(G)** to select the values of operating parameters.
3. Press buttons **(F)** to change the parameter value.
The value of parameter begins to blink.
4. Press button **(H)** to confirm the operation or press button **(L)** to cancel it.
The value of parameter stops blinking and the cursor reaches the next programming area.
5. Repeat the operations described in points 2÷4 until all parameters on the screen page are programmed.

EQUIPMENT CONFIGURATION AT THE FIRST SWITCHING ON

The general operating parameters of the equipment (language, date/ time, unit of measurement, etc.) are preset by the manufacturer in the equipment.



Important

The language selected in these screen pages concerns the general set-ups of the equipment (unit of measurement, audio volume, etc.). The pages with the operating parameters of the machine can be displayed **ONLY** in English.




Follow the instructions.

1. Display "Set-up" screen page.
 2. Press the push-button **(A)**.
 3. Programme all parameters on screen page.
 4. Press the push-button **(B)**.
 5. Programme all parameters on screen page.
- The equipment is now ready to run.




PROGRAMMING THE TWINE BINDING FEATURES




Follow the instructions.

1. Display "Lock screen" screen page.
 2. Press the push-button **(A)**.
 3. Press one of buttons **(B)** to display the desired binding programme.
 4. Check and, if necessary, programme the parameters on screen page.
 5. Press button **(C)** to activate the binding programme.
- The machine is ready to be started for production.



PROGRAMMING THE BALE DENSITY


Bale density programming concerns only the machine version equipped with the variable chamber.



Follow the instructions.

1. Display "Lock screen" screen page.
2. Press the push-button (A).
3. Programme all parameters on screen page.

Set up bale diameters (D1-D2-D3) with a minimum difference of 20÷30 cm among the different values.



To activate the "soft core" function, set up the value "0" in area (P1) (Only for machines equipped with 0 bar valve).

The values assigned to (P1-P2-P3) represent the actual pressure of the hydraulic system for bale density, whose value is shown on the pressure gauge of the machine during work.


Important

**Value (P1) shall not be higher than (P2).
Value (P2) shall not be higher than (P3).**

The machine is ready to be started for production.


ACTIVATION OF BINDERS IN "MANUAL MODE"

Activation of twine guide arms




Follow the instructions.

1. Display "Lock screen" screen page.
2. Press the push-button (A).
3. Press the push-button (B).
4. Press buttons (C) to activate the opening or closing of twine guide arms.





Activation of the twine/net insertion device




Follow the instructions.

1. Display "Lock screen" screen page.
2. Press the push-button (A).
3. Press the push-button (B).
4. Press the push-button (C).
5. Press buttons (D) to activate the opening or closing of twine/net insertion devices.





ACTIVATION OF OPERATING UNITS IN "MANUAL MODE"




Follow the instructions.

1. Display "Lock screen" screen page.
2. Press the push-button (B).
3. Press the push-button (C).
4. Press button (E) to select the desired operating unit in icon (F).
5. Actuate the tractor hydraulic control valve lever and keep it in position in order to lift or lower the selected operating unit.




BALE BINDING IN "AUTOMATIC MODE"

Twine binding




Follow the instructions.

1. Display "Lock screen" screen page.
2. Press button (A) to activate twine binding.
3. Press the push-button (B).
4. Press button (F) to activate the desired binding programme (See #CROSSREFTesto2#).
5. Press the push-button (C).
6. Press the push-button (D).




The machine is ready to be started for production.

Bale binding will automatically start when reaching the set diameter (for machines with variable chamber) or the set density (for machines with fixed chamber).




Net binding



Follow the instructions.

1. Display "Lock screen" screen page.
2. Press button (A) to activate net binding.
3. Press the push-button (B).
4. Programme the number of net binding turns on field (G).
5. Press the push-button (D).




The machine is ready to be started for production.

Bale binding will automatically start when reaching the set diameter (for machines with variable chamber) or the set density (for machines with fixed chamber).

G


BALE BINDING IN "MANUAL MODE"

Twine binding




Follow the instructions.


1. Display "Lock screen" screen page.
2. Press button **(A)** to activate twine binding.
3. Press the push-button **(B)**.
4. Press button **(F)** to activate the desired binding programme (See #CROSSREFTesto2#).



5. Press the push-button **(C)**.
6. Press the push-button **(D)**.
7. When completing the bale, press button **(E)** to activate the binding phase.




Net binding



Follow the instructions.


1. Display "Lock screen" screen page.
2. Press button **(A)** to activate net binding.
3. Press the push-button **(B)**.
4. Programme the number of net binding turns on field **(G)**.
5. Press the push-button **(D)**.



G


6. When completing the bale, press button **(E)** to activate the binding phase.

COUNTER RESET



Follow the instructions.

1. Display "Lock screen" screen page.
2. Press the push-button **(A)**.
3. Press one of buttons **(B)** to display the desired counter.
4. Press the push-button **(C)**.



MAINTENANCE RECOMMENDATIONS

The equipment is not subject to any special maintenance other than normal cleaning, which should be done with a damp cloth.

Important

Do not use liquid products or solvents in order not to damage the materials the equipment is made of.


Care should also be taken to the following:

- Do not expose the equipment to driving rain or to high pressure water jet machines.
- Do not leave the equipment in damp areas or near sources of heat.
- Do not press the display with force and do not use pointed objects to press the push-buttons.
- Do not pull the power supply cable.
- During the winter or extended periods of inactivity keep the equipment in a dry area protected from atmospheric agents.

DISMANTLING THE EQUIPMENT

Do not disperse non biodegradable products and non ferrous components (rubber, PVC, resin, etc.) into the environment. Dispose of them in full respect of the laws in force on the subject.


EQUIPMENT OPERATION TROUBLESHOOTING



In case of a general trouble of the equipment, it is possible to check whether it is caused by the button operation.


Follow the instructions.

1. Display "Set-up" screen page.
2. Press the push-button (A).
3. Press button (B) twice.



The screen page displays the equipment layout

4. Press the push-button (C).
5. Press the buttons of equipment (one at a time) and check whether the corresponding icon is activated on the screen page.



In case of a trouble, refer to the assistance centre authorised by the manufacturer.

6. Press the push-button (C).
The equipment is now ready to run.

TROUBLES, CAUSES, REMEDIES

Any time that an irregularity about machine operation occurs, an acoustic signal turns on and the display shows an alarm message.

Some failures may be resolved by the user; others require precise technical skills or special abilities and must be exclusively resolved by qualified personnel with certified experience, achieved in the specific intervention field.

If malfunctions not included in the chart occur, the user may inform the manufacturer about them so to actively help in developing new solutions and technical and implementation improvements.

In case of need, please apply to the manufacturer's Technical Assistance Service or to an authorised workshop.

The chart lists the messages about possible irregularities, which can occur during the operation, as well as the solutions to remedy them.

Table 1: Operation failures

n°	Alarm description	Cause	Cure
E1	Net operation operating	The net has not been cut properly or it is dragged by the bale.	Restore the proper operation of the net binder unit.
		The net forward potentiometer is not properly regulated.	Contact the Technical Assistance Centre that is authorised by the manufacturer
E2	Net feeding NOT operating	The net is broken or jammed.	Restore the proper operation of the net binder unit.
		The net forward potentiometer is not properly regulated.	Contact the Technical Assistance Centre that is authorised by the manufacturer

Table 1: Operation failures

<i>n°</i>	<i>Alarm description</i>	<i>Cause</i>	<i>Cure</i>
E3	Twine feeding operating	The twine has not been cut properly or it is dragged by the bale.	Restore the proper operation of the twine binder unit.
		The twine forward potentiometers are not properly regulated.	Contact the Technical Assistance Centre that is authorised by the manufacturer
E4	Twine feeding NOT operating	The twine is broken or jammed.	Restore the proper operation of the twine binder unit.
		The twine forward potentiometers are not properly regulated.	Contact the Technical Assistance Centre that is authorised by the manufacturer
E5	Trouble of the twine binder unit motor	Electric motor faulty	Replace the faulty motor or remove the mechanical jams
		The electric motor has a too high power absorption	
E6	Trouble of net/twine insertion device motor	Electric motor faulty	Replace the faulty motor or remove the mechanical jams
		The electric motor has a too high power absorption	
E7	Net cutting knife operating	The net cutting knife does not function properly.	Check the proper operation of the net cutting knife. When confirming the alarm message, the twine/net insertion devices return to the rest position in order to allow the knife reset.
E8	Net NOT cut	At the end of the binding operation, the net is not cut.	Check the proper operation of the net cutting knife.
E9	Trouble of tail gate closing hook (left side)	The bale unloading tail gate has not closed correctly.	Check the correct operation of the sensor.
			Check the efficiency of the sensor and, if necessary, replace it.
			Check the correct operation of the tail gate closing system.
E10	Trouble of tail gate closing hook (left side)	The bale unloading tail gate has not closed correctly.	Check the correct operation of the sensor.
			Check the efficiency of the sensor and, if necessary, replace it.
			Check the correct operation of the tail gate closing system.
E11	Bale diameter too high	The bale diameter is higher than the maximum value allowed	Decrease the forward speed.
		The bale diameter detecting potentiometer is not regulated properly.	Contact the Technical Assistance Centre that is authorised by the manufacturer

Table 1: Operation failures

<i>n°</i>	<i>Alarm description</i>	<i>Cause</i>	<i>Cure</i>
E12	Bale density too high	The bale pressure is higher than the maximum allowed value.	Decrease the forward speed.
		The bale density potentiometers are not regulated properly.	Contact the Technical Assistance Centre that is authorised by the manufacturer
E14	Electric power of "twine/net insertion arm motor" too low	Supply voltage too weak (lower than 9 V)	Turn off the equipment Check the correct operation of the battery and the electric wiring integrity
E15	Power voltage "PWR OUT" too low	Supply voltage too weak (lower than 9 V)	Contact the Technical Assistance Centre that is authorised by the manufacturer
E16	Power voltage "5V OUT" too low	Supply voltage too weak (lower than 4,5 V)	Contact the Technical Assistance Centre that is authorised by the manufacturer
E17	Overheating or overload of electronic card	The temperature of the electronic card is higher than 70°C	Cool down electronic card If the problem persists, refer to the assistance centre authorised by the manufacturer.
E18	Reset of the default values	The default values of the system have been reset.	Contact the Technical Assistance Centre that is authorised by the manufacturer

